



Nios Development Board

Reference Manual, Cyclone Edition



101 Innovation Drive
San Jose, CA 95134
(408) 544-7000
www.altera.com

Document Version: 1.3
Document Date: January 2004

Copyright © 2004 Altera Corporation. All rights reserved. Altera, The Programmable Solutions Company, the stylized Altera logo, specific device designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of Altera Corporation in the U.S. and other countries. All other product or service names are the property of their respective holders. Altera products are protected under numerous U.S. and foreign patents and pending applications, mask work rights, and copyrights. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera Corporation. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.



This manual provides component details about the Nios development board, Cyclone edition.

Table 1 shows the reference manual revision history.

Table 1. Reference Manual Revision History	
Date	Description
January 2004	Pin table corrections.
July 2003	Reflects new directory structure for SOPC Builder 3.0 and Nios Development Kit version 3.1.
May 2003	Minor revisions and edits.
March 2003	First publication of a reference manual. This manual is Cyclone-device specific.

How to Find Information

- The Adobe Acrobat Find feature allows you to search the contents of a PDF file. Click the binoculars toolbar icon to open the Find dialog box.
- Bookmarks serve as an additional table of contents.
- Thumbnail icons, which provide miniature previews of each page, provide a link to the pages.
- Numerous links, shown in green text, allow you to jump to related information.

How to Contact Altera

For the most up-to-date information about Altera products, go to the Altera world-wide web site at <http://www.altera.com>.

For technical support on this product, go to <http://www.altera.com/mysupport>. For additional information about Altera products, consult the sources shown in [Table 2](#).

<i>Table 2. How to Contact Altera</i>		
Information Type	USA & Canada	All Other Locations
Product literature	http://www.altera.com	http://www.altera.com
Altera literature services	lit_req@altera.com (1)	lit_req@altera.com (1)
Non-technical customer service	(800) 767-3753	(408) 544-7000 (7:30 a.m. to 5:30 p.m. Pacific Time)
Technical support	(800) 800-EPLD (3753) (7:30 a.m. to 5:30 p.m. Pacific Time)	(408) 544-7000 (1) (7:30 a.m. to 5:30 p.m. Pacific Time)
	http://www.altera.com/mysupport/	http://www.altera.com/mysupport/
FTP site	ftp.altera.com	ftp.altera.com

Note:

(1) You can also contact your local Altera sales office or sales representative.

Typographic Conventions

This manual uses the typographic conventions shown in [Table 3](#).

<i>Table 3. Conventions</i>	
Visual Cue	Meaning
Bold Type with Initial Capital Letters	Command names, dialog box titles, checkbox options, and dialog box options are shown in bold, initial capital letters. Example: Save As dialog box.
bold type	External timing parameters, directory names, project names, disk drive names, filenames, filename extensions, and software utility names are shown in bold type. Examples: f_{MAX} , \QuartusII directory, d: drive, chiptrip.gdf file.
<i>Bold italic type</i>	Book titles are shown in bold italic type with initial capital letters. Example: <i>1999 Device Data Book</i> .
<i>Italic Type with Initial Capital Letters</i>	Document titles are shown in italic type with initial capital letters. Example: <i>AN 75 (High-Speed Board Design)</i> .
<i>Italic type</i>	Internal timing parameters and variables are shown in italic type. Examples: <i>t_{PIA}</i> , <i>n + 1</i> . Variable names are enclosed in angle brackets (< >) and shown in italic type. Example: <i><file name></i> , <i><project name>.pdf</i> file.
Initial Capital Letters	Keyboard keys and menu names are shown with initial capital letters. Examples: Delete key, the Options menu.
“Subheading Title”	References to sections within a document and titles of Quartus II Help topics are shown in quotation marks. Example: “Configuring a FLEX 10K or FLEX 8000 Device with the BitBlaster™ Download Cable.”
Courier type	Signal and port names are shown in lowercase Courier type. Examples: <code>data1</code> , <code>tdi</code> , <code>input</code> . Active-low signals are denoted by suffix <code>n</code> , e.g., <code>resetn</code> . Anything that must be typed exactly as it appears is shown in Courier type. For example: <code>c:\quartusII\qdesigns\tutorial\chiptrip.gdf</code> . Also, sections of an actual file, such as a Report File, references to parts of files (e.g., the AHDL keyword <code>SUBDESIGN</code>), as well as logic function names (e.g., <code>TRI</code>) are shown in Courier.
1., 2., 3., and a., b., c.,...	Numbered steps are used in a list of items when the sequence of the items is important, such as the steps listed in a procedure.
■	Bullets are used in a list of items when the sequence of the items is not important.
✓	The checkmark indicates a procedure that consists of one step only.
☞	The hand points to information that requires special attention.
↵	The angled arrow indicates you should press the Enter key.
☞	The feet direct you to more information on a particular topic.



Notes:



About this Manual	iii
How to Find Information.....	iii
How to Contact Altera	iv
Typographic Conventions	v
Board Components	9
Features	9
General Description.....	9
Default Reference Design	9
Restoring the Default Reference Design to the Board	10
Block Diagram	11
Nios Development Board Components.....	12
The Cyclone EP1C20 Device	13
Flash Memory Device.....	13
Compact Flash Connector.....	14
SDRAM Device.....	16
Dual SRAM Devices	18
Ethernet MAC /PHY	19
Expansion Prototype Connector (PROTO1)	19
Expansion Prototype Connector (PROTO2)	21
Mictor Connector	23
Serial Port Connectors.....	25
Dual 7-Segment Display	26
Push-Button Switches.....	26
Individual LEDs	27
Serial Configuration Device (EPCS4)	27
Serial Flash Connector.....	27
Configuration Controller Device (EPM7128AE)	28
Reset Distribution	28
Starting Configuration	28
Cyclone Configuration	28
Configuration Data	29
Safe and User Configurations	30
Using Conventional Flash Memory	30
The Configuration-Status LEDs.....	33
Configuration and Reset Buttons	33
SW8 – CPU Reset	34
SW9 – Force Safe	34
SW10 – Reset, Config.....	34

Power-Supply Circuitry	35
Clock Circuitry	35
JTAG Connections	36
JTAG to Cyclone Device (J24)	36
JTAG to MAX Device (J5)	38
Appendix A: Shared Bus Table	39
Appendix B: Restore the Factory Configuration	43
Configuring the Cyclone Device.....	43
Reprogramming the Flash Memory	44
Appendix C: Board Ethernet Connection	45
Connecting the Ethernet Cable	45
Connecting the LCD Display	46
Obtaining an IP address: DHCP	46
IP Addresses for Point-to-Point Connections.....	47
IP Addresses for LAN Connections	48
Browsing your Board	48
Index	49

Features

- A Cyclone™ EP1C20F400C7 device
- 8 Mbytes of flash memory
- 1 Mbyte of static RAM
- 16 Mbytes of SDRAM
- On board logic for configuring the Cyclone device from flash memory
- EPCS4 serial configuration device
- On-board Ethernet MAC/PHY device
- Two 5-V-tolerant expansion/prototype headers each with access to 41 Cyclone user I/O pins
- CompactFlash™ connector header for Type I Compact Flash (CF) cards
- Mictor connector for hardware and software debug
- Two RS-232 DB9 serial ports
- Four push-button switches connected to Cyclone user I/O pins
- Eight LEDs connected to Straix user I/O pins
- Dual 7-segment LED display
- JTAG connectors to Altera devices via Altera download cables
- 50 MHz Oscillator and zero-skew clock distribution circuitry
- Power-on reset circuitry

General Description

The Nios Development Board, Cyclone Edition, provides a hardware platform for developing embedded systems based on Altera Cyclone devices. The Nios development board features a Cyclone EP1C20F400C7 device with 20,060 logic elements (LEs) and 294 Kbits of on-chip memory.

The Nios development board comes pre-programmed with a 32-bit Nios processor reference design. Hardware designers can use the reference design as an example of how to use the features of the Nios development board. Software designers can use the pre-programmed Nios processor design on the board to begin prototyping software immediately.

Default Reference Design

When power is applied to the board, the on-board configuration logic configures the Cyclone FPGA using hardware configuration data stored in flash. When the device is configured, the Nios processor design in the FPGA wakes up and begins executing boot code from flash memory.

The default reference design provides facilities to download new, user-defined software and hardware configuration data to the board from a host computer. Download methods include a serial cable, a JTAG download cable, or an Ethernet cable. The GERMS monitor, an Altera-provided monitor program for the Nios processor, is running on the Console RS-232 serial port (J19). Simultaneously, a web server program is running via the ethernet connection.



The Ethernet port provides a very fast and easy method to download hardware and software images to the board via a web browser on your host computer. For instructions on communicating with your Nios development board via Ethernet, see [“Appendix C: Board Ethernet Connection”](#) on page 45.



See the *Nios Development Kit, Cyclone Edition Getting Started User Guide* for instructions on setting up the Nios development board. See the *Nios Hardware Development Tutorial* for instructions on using this pre-loaded reference design.

Restoring the Default Reference Design to the Board


In the course of development, you may overwrite or erase the flash memory space containing the default reference design. Altera provides the flash image for the default reference design, so that you can always return the board to its default state. These default reference files are located in the Nios development kit examples directory.

See [“Appendix B: Restore the Factory Configuration”](#) on page 43 for more information.

Block Diagram

Figure 1 shows a block diagram of the board.

Figure 1. Nios Development Board, Cyclone Edition Block Diagram




Nios Development Board Components

This section contains a brief overview of important components on the Nios development board (see [Figure 2](#)). Links to the component manufacturers are included when available.

A complete set of schematics, a physical layout database, and GERBER files for the Nios development board are installed in the **documents** directory for the Nios development kit.

Figure 2. Nios Development Board Components



The Cyclone EP1C20 Device

U60 is a Cyclone EP1C20F400C7 device in a 400-pin FineLine BGA[®] package. [Table 4](#) lists the Cyclone device features.

Logic Elements	20,060
M4K RAM blocks (128 X 36 bits)	64
Total RAM bits	294,912
PLLs	2
Maximum user I/O pins	301

The development board provides two separate methods for configuring the Cyclone device:

1. Using the Quartus II software running on a host computer, a designer configures the device directly via an Altera download cable connected to the Cyclone JTAG header (J24).
2. When power is applied to the board, a configuration controller device (U3) attempts to configure the Cyclone device with hardware configuration data stored in flash memory. For more information on the configuration controller, see [“Configuration Controller Device \(EPM7128AE\)” on page 28](#).



See the Altera Cyclone literature page for Cyclone-related documentation at www.altera.com/literature/lit-cyc.html including a Cyclone EP1C20 pinout document.

Flash Memory Device

U5 is an 8 Mbyte AMD AM29LV065D flash memory device connected to the Cyclone device and can be used for two purposes:

1. A Nios embedded processor implemented on the Cyclone device can use the flash memory as general-purpose readable memory and non-volatile storage.
2. The flash memory can hold Cyclone configuration data that is used by the configuration controller to load the Cyclone device at power-up. See [“Configuration Controller Device \(EPM7128AE\)” on page 28](#) for related information.

Hardware configuration data that implements the Nios reference design is pre-stored in this flash memory. The pre-loaded Nios reference design, once loaded, can identify the 8 Mbyte flash memory in its address space and includes monitor software that can download files (either new Cyclone configuration data, Nios embedded processor software, or both) into flash memory. The Nios embedded processor software includes subroutines for writing and erasing this specific type of AMD flash memory.

The flash memory device shares address and data connections with the SRAM chips and the Ethernet MAC/PHY chip. For shared bus information, see “[Appendix A: Shared Bus Table](#)” on page 39.


See www.amd.com for detailed information about the flash memory device.

Compact Flash Connector

The compact flash connector (CON3) enables hardware designs to access a compact flash card (see [Figure 3](#)). The following two access modes are supported:

- ATA (hot swappable mode)
- IDE (IDE hard disk mode)

Figure 3. Compact Flash Connector



The IDE connection mode includes a power MOSFET which controls power to the compact flash card. This MOSFET is controllable through an IO pin on the Cyclone device.


 The compact flash connector shares several Cyclone I/O pins with expansion prototype connector header (PROTO1), see “[Expansion Prototype Connector \(PROTO1\)](#)” on page 19 for PROTO1 details.

Table 5 below provides compact flash pin out details

Table 5. Compact Flash (CON3) Pin Table (Part 1 of 2)		
Cyclone Device Pin (U60)	Compact Flash Pin (CON3)	Compact Flash Function
GND	1	GND
F18	2	D03
E17	3	D04
D17	4	D05
D18	5	D06
C18	6	D07
H20	7	-CE
J15	8	A10
D13	9	-OE
J20	10	A09
H14	11	A08
J14	12	A07
VCC	13	VCC
J17	14	A06
J18	15	A05
K15	16	A04
W18	17	A03
H19	18	A02
H18	19	A01
H17	20	A00
F20	21	D00
F15	22	D01
E19	23	D02
H16	24	WP
GND	25	-CD2
B13	26	-CD1
F17	27	D11
E18	28	D12
F16	29	D13
F19	30	D14
G16	31	D15
U19	32	-CE2
GND	33	-VS1
G19	34	-OIRD

Table 5. Compact Flash (CON3) Pin Table (Part 2 of 2)

Cyclone Device Pin (U60)	Compact Flash Pin (CON3)	Compact Flash Function
G20	35	-IOWR
V18	36	-WE
G17	37	RDY/BSY
VCC	38	VCC
GND	39	-CSEL
NC	40	-VS2
RESET_n	41	RESET
G14	42	-WAIT
V19	43	-INPACK
U20	44	-REG
J16	45	BVD2
J19	46	BVD1
C19	47	D081
D19	48	D091
D20	49	D101
GND	50	GND



See www.molex.com for more compact flash connector (CON3) information. See www.compactflash.org for more information on the compact flash connector.

SDRAM Device

The SDRAM device (U57) is a Micron MT48LC4M32B2 chip with PC100 functionality and self refresh mode. The SDRAM is fully synchronous with all signals registered on the positive edge of the system clock (c1k).

The SDRAM device pins are connected to the Cyclone device (see [Table 6](#)). An SDRAM controller peripheral is included with the Nios development kit, allowing a Nios processor to view the SDRAM device as a large, linearly addressable memory.

Table 6. SDRAM (U57) Pin Table (Part 1 of 3)

Pin Name	Pin Number	Connects to Cyclone Pin
A0	25	M2
A1	26	M1
A2	27	M6
A3	60	M4

Table 6. SDRAM (U57) Pin Table (Part 2 of 3)

Pin Name	Pin Number	Connects to Cyclone Pin
A4	61	J8
A5	62	J7
A6	63	J6
A7	64	J5
A8	65	J4
A9	66	J3
A10	24	H6
A11	21	H5
BA0	22	H7
BA1	23	H1
DQ0	2	M5
DQ1	4	M3
DQ2	5	M7
DQ3	7	N6
DQ4	8	N1
DQ5	10	N2
DQ6	11	N4
DQ7	13	N3
DQ8	74	N5
DQ9	76	N7
DQ10	77	P7
DQ11	79	P2
DQ12	80	P1
DQ13	82	P6
DQ14	83	P5
DQ15	85	P3
DQ16	31	P4
DQ17	33	R1
DQ18	34	R2
DQ19	36	R6
DQ20	37	R5
DQ21	39	R3
DQ22	40	R4
DQ23	42	T4
DQ24	45	T2
DQ25	47	T3
DQ26	48	U1

Table 6. SDRAM (U57) Pin Table (Part 3 of 3)

Pin Name	Pin Number	Connects to Cyclone Pin
DQ27	50	U4
DQ28	51	U2
DQ29	53	U3
DQ30	54	V3
DQ31	56	V2
DQM0	16	J2
DQM1	71	J1
DQM2	28	H4
DQM3	59	H3
RAS_N	19	H2
CAS_N	18	G3
CKE	67	G7
CS_N	20	G6
WE_N	17	G4
CLK	68	L13



See www.micron.com for detailed SDRAM information.

Dual SRAM Devices

U35 and U36 are two (512 Kbyte x 16-bit) asynchronous SRAM devices. They are connected to the Cyclone device so they can be used by a Nios embedded processor as general-purpose memory. The two 16-bit devices can be used in parallel to implement a 32-bit wide memory subsystem. The pre-loaded Nios reference design identifies these SRAM devices in its address space as a contiguous 1Mbyte, 32-bit-wide, zero-wait-state main memory.


The SRAM devices share address and data connections with the flash memory and the Ethernet MAC/PHY device. For shared bus information, see “[Appendix A: Shared Bus Table](#)” on page 39.



See www.idt.com for detailed information about the SRAM devices.

Ethernet MAC/PHY

The LAN91C111 (U4) is a mixed signal analog/digital device that implements protocols at 10Mbps and 100 Mbps. The control pins of U4 are connected to the Cyclone device so that Nios systems can access Ethernet via the RJ-45 connector (RJ1). See [Figure 4 on page 19](#). The Nios development kit includes hardware and software components that allow Nios processor systems to communicate with the LAN91C111 Ethernet device.

Figure 4. Ethernet MAC/PHY Device

The Ethernet MAC/PHY device share address and data connections with the flash memory and the SRAM chips. For shared bus information, see “Appendix A: Shared Bus Table” on page 39.



See www.smsc.com for detailed information about the LAN91C111 device. See the *Plugs Ethernet Library Reference Manual* for details on accessing the MAC/PHY device in Nios software.

Expansion Prototype Connector (PROTO1)

The PROTO1 expansion prototype connectors share Cyclone IO pins with the compact flash connector. Designs may use either the PROTO1 connectors or the compact flash.

Headers J11, J12, and J13 collectively form the standard-footprint, mechanically-stable connection that can be used (for example) as an interface to a special-function daughter card.



See the Altera web site for a list of available expansion daughter cards that can be used with the Nios development board at www.altera.com/devkits.

The expansion prototype connector interface includes:

- 41 I/O pins for prototyping. All 41 I/O pins connect to user I/O pins on the Cyclone device. Each signal passes through analog switches (U19, U20, U21, U22 and U25) to protect the Cyclone device from 5-V logic levels. These analog switches are permanently enabled.
- A buffered, zero-skew copy of the on-board OSC output from U2.
- A buffered, zero-skew copy of the Cyclone's phase-locked loop (PLL)-output from U60.
- A logic-negative power-on reset signal
- Five regulated 3.3-V power-supply pins (2A total max load for both PROTO1 & PROTO2)
- One regulated 5-V power-supply pin (1A total max load for both PROTO1 & PROTO2)
- Numerous ground connections

The output logic level on the expansion prototype connector pins is 3.3V. The power supply included with the Nios development kit cannot supply the maximum load current specified above.

Figure 5, Figure 6 on page 20 and Figure 7 on page 21 show connections from the PROTO1 expansion headers to the Cyclone device. Unless otherwise noted, labels indicate Cyclone device pin numbers.

Figure 5. Expansion Prototype Connector - J11




Figure 6. Expansion Prototype Connector - J12





Figure 7. Expansion Prototype Connector - J13**Note to Figure 7**

- (1) Unregulated voltage from AC to DC power transformer.
- (2) Clk from board oscillator.
- (3) Clk from PLD via buffer.
- (4) Clk output from protocard to PLD.

Expansion Prototype Connector (PROTO2)

Headers J15, J16, and J17 collectively form the standard-footprint, mechanically-stable connection that can be used (for example) as an interface to a special-function daughter card.

The expansion prototype connector interface includes:

- 41 I/O pins for prototyping. All 41 I/O pins connect to user I/O pins on the Cyclone device. Each signal passes through analog switches (U27, U28, U29, U30 and U31) to protect the Cyclone device from 5-V logic levels. These analog switches are permanently enabled.
- A buffered, zero-skew copy of the on-board OSC output (from U2).
- A buffered, zero-skew copy of the Cyclone's phase-locked loop (PLL)-output (from U60)
- A logic-negative power-on-reset signal
- Five regulated 3.3-V power-supply pins (2A total max load for both PROTO1 & PROTO2)
- One regulated 5-V power-supply pin (1A total max load for both PROTO1 & PROTO2)
- Numerous ground connections

The output logic level on the expansion prototype connector pins is 3.3V. The power supply included with the Nios development kit cannot supply the maximum load current specified above.

Figure 8 on page 22, Figure 9 on page 22 and Figure 10 on page 23 show connections from the PROTO2 expansion headers to the Cyclone device. Unless otherwise noted, labels indicate Cyclone device pin numbers.

Figure 8. Expansion Prototype Connector - J16




Figure 9. Expansion Prototype Connector - J15





Figure 10. Expansion Prototype Connector - J17**Note to Figure 10**

- (1) Unregulated voltage from AC to DC power transformer.
- (2) Clk from board oscillator.
- (3) Clk from PLD via buffer.
- (4) Clk output from protocard to PLD.

Mictor Connector

The Mictor connector (J25) can be used to transmit up to 27 high-speed I/O signals with very low noise via a shielded Mictor cable. J25 is used as a debug port. Twenty five of the Mictor connector signals are used as data, and two signals are used as clock input and clock output.

Most Mictor connector pins on J25 connect to I/O pins on the Cyclone device (U60). For systems that do not use the Mictor connector for the Nios OCI debug module, any on-chip signals can be routed to I/O pins and probed at J25 via a Mictor cable. External scopes and logic analyzers can connect to J25 and analyze a large number of signals simultaneously.




The Nios OCI debug module is the First Silicon Solutions Inc. (FS2) OCI core.



See the [Nios Development Software Tutorial](#) for the more information about the OCI debug module.

Figure 11 on page 24 shows an example of an in-target system analyzer ISA-NIOS/T (sold separately) by First Silicon Solutions (FS2) Inc. For details see www.fs2.com.

Figure 11. Mictor Debug Port to OCI Debug Module



Five of the signals connect directly to the JTAG pins on the Cyclone device (U60), and also connect directly to the Cyclone device's JTAG connector (J24). The JTAG signals have special usage requirements. You cannot use J24 and J25 at the same time.

Figure 12 below shows connections from the Mictor connector to the Cyclone device. Figure 13 on page 25 shows the pin out for J25. Unless otherwise noted, labels indicate Cyclone device pin numbers.

Figure 12. Mictor Connector Signaling





Figure 13. Debug Mictor Connector - J25



Serial Port Connectors

J19 & J27 are standard DB-9 serial connectors. These connectors are typically used for communication with a host computer using a standard, 9-pin serial cable connected to (for example) a COM port. Level-shifting buffers (U52 and U58) are used between J19 & J27 and the Cyclone device, because the Cyclone device cannot interface to RS-232 voltage levels directly.

The Nios development board provides two serial connectors, one labeled Console and the other labeled Debug. Many processor systems make use of multiple UART communication channels during prototype and debug stages.

The console serial port is able to transmit all RS-232 signals. Alternately, the Cyclone design may use only the signals it needs, such as RXD and TXD. LEDs are connected to the RXD and TXD signals, giving a visual indication when data is being transmitted or received. [Figure 14](#) and [Figure 15](#) show the pin connections between the Console and Debug serial connectors and the Cyclone device.

Figure 14. Console Serial Port Connector - J19






Figure 15. Debug Serial Port Connector – J27

Dual 7-Segment Display

U8 and U9 are connected to the Cyclone device so that each segment is individually controlled by a general-purpose I/O pin. When the Cyclone pin drives logic 0, the corresponding LED turns on. See [Figure 16](#) for Cyclone device pin out details.

Figure 16. Dual-7-Segment Display

The pre-loaded Nios reference design includes parallel input/output (PIO) registers and logic for driving this display.

Push-Button Switches

SW0 – SW3 are momentary-contact push-button switches that provide stimulus to designs in the Cyclone device. See [Figure 17 on page 27](#). Each switch is connected to an Cyclone general-purpose I/O pin with a pull-up resistor as shown in [Table 7](#). The Cyclone device pin will see a logic 0 when each switch is pressed.

Table 7. Push Button Switches Pin Out Table


Button	SW0	SW1	SW2	SW3
Cyclone Pin	W3	Y4	V4	W4

Individual LEDs

This Nios development board provides eight individual LEDs connected to the Cyclone device. See [Figure 17 on page 27](#). D0 – D7 are connected to general purpose I/O pins on the Cyclone device as shown in [Table 8](#). When the Cyclone pin drives logic 1, the corresponding LED turns on.

LED	D0	D1	D2	D3	D4	D5	D6	D7
Cyclone Pin	E14	E13	C14	D14	E12	F12	B3	B14

Figure 17. SW0 – SW3 Push Button Switches and Individual LEDs



Serial Configuration Device (EPCS4)

Serial configuration devices are flash memory devices with a serial interface that can store configuration data for a Cyclone device and reload the data to the device upon power-up or re-configuration. With the new data-decompression feature in the Cyclone FPGA family, designers can use smaller serial configuration devices to configure larger Cyclone FPGAs. Serial configuration devices cannot be cascaded.

The SOPC Builder active serial memory interface component allows microprocessor systems access to serial configuration memory.

Serial Flash Connector

The serial flash connector logic is designed strictly for an EPCS4 serial configuration device connection. Hardware designers will never need the serial flash connector for using the reference designs that came with the Nios development kit. The reference designs allow the designer to access data from the serial configuration device without using this connector. See [“Cyclone Configuration” on page 28](#).



The ByteBlaster II download cable is required when using the serial flash connector for connecting to the EPCS4 serial configuration device.



See the [Serial Configuration Devices \(EPCS1 & EPCS4\) Data Sheet](#) at for more information about this device and the [Active Serial Memory Interface Data Sheet](#) for information about the active serial memory interface component in SOPC Builder.

Configuration Controller Device (EPM7128AE)

The configuration controller (U3), is an Altera EPM7128AE device. It comes pre-programmed with logic for managing board reset conditions and configuring the Cyclone device from data stored in flash memory and the EPCS4 serial configuration device.

Reset Distribution

The EPM7128AE takes a power-on reset pulse from the Linear Technologies 1326 power-sense/reset-generator chip and distributes it (through internal logic) to other reset-pins on the board, including the:

- LAN91C111 (Ethernet MAC/PHY) reset
- Flash memory reset
- Reset signals delivered to the expansion prototype connector headers (PROTO1 & PROTO2)

Starting Configuration

There are four methods to start a configuration sequence. The four methods are the following:

1. Board power-on.
2. Pressing the Reset, Config button (SW10).
3. Asserting (driving 0 volts on) the MAX's `reconfigreq_n` input pin (from a Cyclone design).
4. Pressing the Force Safe button (SW9).

Cyclone Configuration

At power-up or reset, the configuration controller attempts to configure the Cyclone device with data from one of three sources, in the following order:

- First—The EPCS4 serial configuration device
- Second—The User configuration from flash memory
- Third—The Safe configuration from flash memory

First, the configuration controller puts the Cyclone FPGA in active serial (AS) configuration mode. The Cyclone FPGA will then attempt to read configuration data from the EPCS4. If the Cyclone FPGA is successfully configured, the configuration controller stops.

If configuration from the EPCS4 was not successful, the configuration controller puts the Cyclone FPGA into passive serial mode and attempts to load the user configuration from flash memory. If this also fails, the configuration controller attempts to load the safe configuration in flash memory.

When SW9 (Force Safe) is pressed, the configuration controller immediately begins configuring the Cyclone FPGA from the safe configuration in flash memory—data in the EPCS4 and in the User Hardware Image are ignored.

Most users will never need to re-program the configuration controller. Reprogramming the configuration controller may result in an inoperable development board. A programming file (**config_controller.pof**) with the original configuration controller logic is included with the Nios development kit. If you have changed the MAX device logic, you can restore the factory configuration using this programming file located in the **EPM7128_flash_config_controller** folder of the **examples** directory for this board.

See the MAX7000 device literature at www.altera.com/literature/lit-m7k.html for detailed information about the Altera EPM7128AE device (Altera MAX[®] 7000 family).

Configuration Data

The Quartus II software can (optionally) produce hexout configuration files that are directly suitable for download and storage in the flash memory as configuration data. A hexout configuration file for the Cyclone EP1C20 device (U60) is a little less than 1 Mbyte, and occupies about one eighth of the flash memory (U5).

New hexout files can be stored in the flash memory (U5) by software running on a Nios embedded processor. The Nios pre-loaded reference design includes facilities for downloading hexout files from a host (such as desktop workstation) into flash memory.



See the *Nios Embedded Processor Software Development Reference Manual* for detailed information.

Safe and User Configurations

The configuration controller can manage three separate Cyclone device configurations: one configuration stored in the EPSC4 configuration device, and two configurations stored in flash memory. These two configurations stored in flash memory are conventionally referred to as the safe configuration and the user configuration.

The configuration controller expects user configuration and safe configuration files to be stored at fixed locations (offsets) in flash memory. Table 10 on page 32 shows how the configuration controller expects flash memory contents to be arranged.



A Nios reference design is pre-loaded into the safe-configuration region of the flash memory. Altera recommends that users avoid overwriting the safe configuration data.

If SW9 (Force Safe) is pressed, the configuration controller will ignore the user-configuration and always configure the Cyclone device from the safe configuration. This switch allows you to “escape” from the situation where a valid-but-nonfunctional user configuration is present in flash memory or the serial configuration device.



See the *Nios Embedded Processor Software Development Reference Manual* for detailed information about downloading and relocating files using the GERMS monitor.

Using Conventional Flash Memory

The Nios Development Board includes an 8 MByte flash memory device (U5). See Table 9. It is divided into 128 individually-erasable 64K sectors. This web-server design, and (more importantly) the on-board configuration controller, makes certain assumptions about what resides where in flash memory.

Each of the upper four (4) Mbytes of flash memory are used by either the configuration controller or the web server. Your application software may safely use the lower half (4 MBytes) of flash memory without interfering with FPGA configuration or web-server operation.

Address (hex)	Flash Allocation
000000	4MB
100000	
200000	
300000	
400000	Web Pages (2MB)
500000	
600000	User Configuration Data (1 MB)
700000	Safe Configuration Data (1 MB)

Factory-programmed—**do not erase** Available for user data.



The factory-programmed reference design implements a web server. Network settings and web pages are pre-programmed in the flash memory, as shown in Table 10 on page 32.



WARNING: The **safe example** design is provided for reference only. Do not base your hardware or software designs on the safe example design. Use the **standard_32 example** design.

User Hardware Image

At power on, or when the Reset, Config button (SW10) is pressed, the configuration controller begins reading user configuration data out of flash at address 0x600000. This data, and suitable control signals, are used in an attempt to configure the FPGA. FPGA configuration data written into this region of flash memory is conventionally called the **User Hardware Image**. The web server includes documentation on how to create your own **User Hardware Image** data and several facilities for burning your **User Hardware Image** into flash memory.

Safe Hardware Image

If there is no valid **User Hardware Image**, or if SW9 (Force Safe) is pressed, the configuration controller begins reading data out of flash at address 0x700000. Any FPGA configuration data stored at this location is conventionally called the **Safe Hardware Image**. Your development board was factory-programmed with a **Safe Hardware Image**, plus additional data located in the range 0x700000-0x7FFFFFFF, as shown in [Table 10](#). The design used for the **Safe Hardware Image** is the **safe example** design found in the **examples** directory.

The configuration controller will stop reading data when the FPGA successfully configures. The **safe example** design is setup to begin executing code from address 0x7B0000. This region of flash memory is programmed with the web-server application software.



Do Not Erase your **Safe Hardware Image** (safe hardware configuration data). If you do so inadvertently, see [“Appendix B: Restore the Factory Configuration”](#) on page 43 for instructions on how to restore your board to its factory configuration.

Address (hex)	Safe Hardware Image	
700000	FPGA Configuration Data	
710000		
720000		
730000		
740000		
750000		
760000		
770000		
780000		
790000		
7A0000		
7B0000		Web Server Software
7C0000		
7D0000		
7E0000		
7F0000	Network Settings	

The Configuration-Status LEDs

The MAX device is connected to four status LEDs that show the configuration status of the board at a glance (see Figure 18). The user can tell which configuration, if any, was loaded into the board at power-on by looking at the LEDs (see Table 11 on page 33). If a new configuration was downloaded into the Cyclone device via JTAG, then all of the LEDs will turn off.

Figure 18. LED1 – LED4




Table 11. Configuration Status LED Indicators

LED	LED Name	Color	Description
LED3	Loading	Green	This LED blinks while the MAX configuration-controller is actively transferring data from flash memory into the Cyclone FPGA.
LED4	Error	Red	If the red Error LED is on, then configuration was NOT transferred from flash memory into the Cyclone device. This can happen if, for example, the flash memory contains neither a valid user or safe configuration.
LED1	User	Green	If the Cyclone device was successfully configured with data from the EPCS4, LED1 will blink slowly. If the Cyclone device was successfully loaded with the user configuration from flash memory, LED1 will remain on continuously.
LED2	Force Safe	Amber	This LED turns on when the safe configuration is being transferred from flash memory and stays illuminated if the safe configuration was successfully loaded into the Cyclone device.

Configuration and Reset Buttons


The Nios development board uses dedicated switches SW8, SW9 and SW10 for the following fixed functions:

SW8 – CPU Reset

When SW8 is pressed, a logic-0 is driven onto the Cyclone devices' DEV_CLRn pin (and user I/O C_4). The result of pressing SW8 depends on how the Cyclone device is currently configured.

The pre-loaded Nios reference design treats SW8 as a CPU-reset pin (see [Figure 19](#)). The reference Nios CPU will reset and start executing code from its reset address when SW8 is pressed.

Figure 19. Safe Config Button




SW9 – Force Safe

Pressing Force Safe (SW9) commands the configuration controller to re-configure the Cyclone device with the factory-programmed safe configuration.

SW10 – Reset, Config

Reset, Config (SW10) is the power-on reset button (see [Figure 20](#)). When SW10 is pressed, a logic 0 is driven to the power-on reset controller (U18). See [“Power-Supply Circuitry” on page 35](#) for more details. After SW10 is pressed, the configuration controller will load the Cyclone device from flash memory. See [“Configuration Controller Device \(EPM7128AE\)” on page 28](#) for more information.

Figure 20. Reset, Config Button



Power-Supply Circuitry


The Nios development board runs from a 9-V, unregulated, center-negative input power supply. On-board circuitry generates 5-V, 3.3-V, and 1.5-V regulated power levels.

- The 5-V supply is present on pin 2 of J12 and J15 for use by any device plugged into the PROTO1 or PROTO2 expansion connectors.
- The 3.3-V supply is used as the power source for all Cyclone device I/O pins. The 3.3-V supply is also available to PROTO1 & PROTO2 daughter cards.
- The 1.5-V supply is used only as the power supply for the Cyclone device core (VCCint) and it is not available on any connector or header.

Clock Circuitry

The Nios development board includes a 50 MHz free-running oscillator and a zero-skew, point-to-point clock distribution network. The clock network drives the Cyclone device and pins on the expansion prototype connectors, the configuration controller device, and the Mictor connector. The zero-skew buffer distributes both the free-running 50 MHz clock and the clock-output from one of the Cyclone's device internal PLLs (CLKLK_OUT1). See [Figure 21](#).

Figure 21. Clock Circuitry



Note to [Figure 21](#):


- (1) An external clock can be enabled by stuffing location R15 with a 49.9 ohm 0603 resistor and stuffing location R13 with a 330 ohm 0603 resistor.

A socketed 50 MHz free-running oscillator (Y2) supplies the fundamental operating frequency, and a clock buffer (U2) drives zero-skew clock signals to various points on the board.

The Cyclone device can synthesize a new clock signal internally using on-chip PLLs, and distribute the clock to various locations on the board by outputting the clock signal to the IO_PLL1_OUT0_p pin. The clock buffer drives this signal to the following locations:

- The PROTO1_CLKIN and PROTO2_CLKIN pins on the expansion prototype connectors, allowing a user-defined clock to drive each of the expansion prototype headers.
- The clock input for the SDRAM memory (U57), allowing SDRAM to run at a different rate than the clock oscillator.
- The CLK0 clock input on the Cyclone device.

The Cyclone device can also supply a clock from the IO_PLL2_OUT0_p pin to the SDRAM (U57).



 The 50 MHz oscillator (Y2) is socketed and can be changed by the user. However, the MAX EPM7128AE device configuration control circuit and other Altera reference designs are not guaranteed to work at different frequencies. It is the user's responsibility to accommodate a new clock oscillator when designing a system.

JTAG Connections

The Nios development board, has two 10-pin JTAG headers (J5 and J24) compatible with the Altera ByteBlaster II download cable. Each JTAG header connects to one Altera device and forms a single-device JTAG chain. J24 connects to the Cyclone device (U60), and J5 connects to the MAX EPM7128AE device (U3).

JTAG to Cyclone Device (J24)

J24 connects to the JTAG pins (TCK, TDI, TDO, TMS, TRST) of the Cyclone device (U60) as shown in [Figure 22 on page 37](#). Altera Quartus II software can directly configure the Cyclone device with a new hardware image via an Altera ByteBlaster II download cable as shown in [Figure 23 on page 37](#). In addition, Nios embedded processor debugger software can access the Nios OCI debug module via a download cable connected to the J24 JTAG connector.


Figure 22. JTAG Connector (J24) to Cyclone Device**Figure 23. JTAG Connection to Download Cable**

The Cyclone device's JTAG pins can also be accessed via the Mictor connector (J25). The pins of J24 are connected directly to pins on J25, and care must be taken so that signal contention does not occur between the two connectors.

JTAG to MAX Device (J5)

J5 connects to the JTAG pins (TCK, TDI, TDO, TMS, TRST) of the MAX device (U3) as shown in [Figure 24](#). Altera Quartus II software can perform in-system programming (ISP) to reprogram the MAX device (U3) with a new hardware configuration via an Altera ByteBlaster II download cable.

Figure 24. JTAG Connector (J5) to MAX Device





Appendix A: Shared Bus Table

On the Nios Development Board, Cyclone Edition, the flash memory, SRAM and Ethernet MAC/PHY devices share address and control lines. These shared lines are referred to as the Shared Bus. Using SOPC Builder, designers can interface a Nios processor system to any device connected to the off-chip shared bus.

Table 12 on page 40 lists all connections between the devices connected to the shared bus.

Table 12. Shared Bus Table (Part 1 of 3)

NET Name	NET Description	PLD (U60)		Flash (U5)		SRAM (U35)		SRAM (U36)		Ethernet (U4)	
		Pin Name	Pin #	Pin Name	Pin #	Pin Name	Pin #	Pin Name	Pin #	Pin Name	Pin #
FSE_A0	Shared Address	IO	B4	A0	27						
FSE_A1		IO	A4	A1	22					A1	78
FSE_A2		IO	D5	A2	21	A0	1	A0	1	A2	79
FSE_A3		IO	D6	A3	20	A1	2	A1	2	A3	80
FSE_A4		IO	C5	A4	19	A2	3	A2	3	A4	81
FSE_A5		IO	B5	A5	18	A3	4	A3	4	A5	82
FSE_A6		IO	C2	A6	17	A4	5	A4	5	A6	83
FSE_A7		IO	D2	A7	16	A5	18	A5	18	A7	84
FSE_A8		IO	D4	A8	10	A6	19	A6	19	A8	85
FSE_A9		IO	D1	A9	9	A7	20	A7	20	A9	86
FSE_A10		IO	E4	A10	42	A8	21	A8	21	A10	87
FSE_A11		IO	E5	A11	8	A9	22	A9	22	A11	88
FSE_A12		IO	F3	A12	7	A10	23	A10	23	A12	89
FSE_A13		IO	E3	A13	6	A11	24	A11	24	A13	90
FSE_A14		IO	E2	A14	5	A12	25	A12	25	A14	91
FSE_A15		IO	F4	A15	4	A13	26	A13	26	A15	92
FSE_A16		IO	F5	A16	3	A14	27	A14	27		
FSE_A17		IO	F2	A17	46	A15	42	A15	42		
FSE_A18		IO	F1	A18	15	A16	43	A16	43		
FSE_A19		IO	F6	A19	43	A17	44	A17	44		
FSE_A20		IO	G5	A20	44						
FSE_A21		IO	G1	A21	35						
FSE_A22	IO	G2	A22	2							

Table 12. Shared Bus Table (Part 2 of 3)

NET Name	NET Description	PLD (U60)		Flash (U5)		SRAM (U35)		SRAM (U36)		Ethernet (U4)	
FSE_D0	Shared Data	IO	C6	D0	31	D0	7			D0	107
FSE_D1		IO	E6	D1	32	D1	8			D1	106
FSE_D2		IO	B6	D2	33	D2	9			D2	105
FSE_D3		IO	A6	D3	34	D3	10			D3	104
FSE_D4		IO	F7	D4	38	D4	13			D4	102
FSE_D5		IO	E7	D5	39	D5	14			D5	101
FSE_D6		IO	B7	D6	40	D6	15			D6	100
FSE_D7		IO	A7	D7	41	D7	16			D7	99
FSE_D8		IO	D7			D8	29			D8	76
FSE_D9		IO	C7			D9	30			D9	75
FSE_D10		IO	F8			D10	31			D10	74
FSE_D11		IO	E8			D11	32			D11	73
FSE_D12		IO	B8			D12	35			D12	71
FSE_D13		IO	A8			D13	36			D13	70
FSE_D14		IO	D8			D14	37			D14	69
FSE_D15		IO	C8			D15	38			D15	68
FSE_D16		IO	B9					D0	7	D16	66
FSE_D17		IO	A9					D1	8	D17	65
FSE_D18		IO	D9					D2	9	D18	64
FSE_D19		IO	C9					D3	10	D19	63
FSE_D20		IO	E9					D4	13	D20	61
FSE_D21		IO	E10					D5	14	D21	60
FSE_D22		IO	B10					D6	15	D22	59
FSE_D23		IO	A10					D7	16	D23	58
FSE_D24		IO	F10					D8	29	D24	56
FSE_D25		IO	C10					D9	30	D25	55
FSE_D26		IO	D10					D10	31	D26	54
FSE_D27		IO	C11					D11	32	D27	53
FSE_D28		IO	D11					D12	35	D28	51
FSE_D29		IO	B11					D13	36	D29	50
FSE_D30		IO	A11					D14	37	D30	49
FSE_D31	IO	E11					D15	38	D31	48	

<i>Table 12. Shared Bus Table (Part 3 of 3)</i>											
NET Name	NET Description	PLD (U60)		Flash (U5)		SRAM (U35)		SRAM (U36)		Ethernet (U4)	
FLASH_CS_n	Chip Select	IO	A12	CE_n	28						
FLASH_OE_N	Read Enable	IO	B12	OE_n	30						
FLASH_RW-N	Write Enable	IO	D12	WE_n	11						
FLASH_RY-BY_N	Ready/Busy	IO	C12	RY/BY_n	14						
SRAM_BE_N0	Byte Enable 0	IO	V17			BE0#	39				
SRAM_BE_N1	Byte Enable 1	IO	V16			BE1#	40				
SRAM_BE_N2	Byte Enable 2	IO	W16					BE2#	39		
SRAM_BE_N3	Byte Enable 3	IO	T16					BE3#	40		
SRAM_CS_N	Chip Select	IO	W17			CS_n	6	CS_n	6		
SRAM_OE_N	Read Enable	IO	Y17			OE_n	41	OE_n	41		
SRAM_WE_N	Write Enable	IO	U16			WE_n	17	WE_n	17		
ENET_ADS_N	Address Strobe	IO	A14								
ENET_AEN	Address Enable	IO	B15	AEN	41						
ENET_BE_N0	Byte Enable 0	IO	C16	BE0#	94						
ENET_BE_N1	Byte Enable 1	IO	B16	BE1#	95						
ENET_BE_N2	Byte Enable 2	IO	D16	BE2#	96						
ENET_BE_N3	Byte Enable 3	IO	E16	BE3#	97						
ENET_CYCLE_N	Bus Cycle	IO	B17	CYCLE#	35						
ENET_DATAACS_N	Data Chip Select	IO	C15	DATAACS#	34						
ENET_INTRQ0	Interrupt	IO	D15	INTRO	29						
ENET_IOCHRDY	IO Char Ready	IO	F14	ARDY	38						
ENET_IOR_N	Read	IO	A15	RD#	31						
ENET_IOW_N	Write	IO	E15	WR#	32						
ENET_LCLK	Local Bus Clock	IO	C17	LCLK	42						
ENET_LDEV_N	Local Device	IO	D3	LDEV#	45						
ENET_RDYRTN_N	Ready Return	IO	B18	RDYRTN#	46						
ENET_W_R_N	Write/Read	IO	A17	W/R#	36						

The Nios development board can always be restored to its factory-programmed configuration. To restore the factory configuration, you must reprogram the flash memory on the Nios development board.

Reprogramming the flash memory requires the following:

- A Nios processor hardware design configured in the Cyclone device and executing the GERMS monitor.
- The factory flash image for GERMS to program into the flash memory.

Configuring the Cyclone Device

With the above mentioned requirements, perform the following steps:

1. Connect the Nios development board to the host computer using the ByteBlasterII download cable.
2. Launch the Quartus II software and open the Programmer window (Tools menu).
3. Click **Add File...** and select the following configuration file:

```
<Nios Development Kit <install directory>/examples/  
recovery_configuration_cyclone_1c20.sof
```

4. In the Programmer window, check the **Program/Configure** box, and click **Start** to download the hardware configuration.
5. After configuration completes, hold down SW0, press and release SW8 and then release SW0.

The Cyclone device is configured with a Nios processor hardware design executing the GERMS monitor. At this stage, **DO NOT** push the Force Safe or Reset, Config buttons, because it will reset the Cyclone configuration.



See the [Nios Hardware Development Tutorial](#) for a detailed description of configuring the Cyclone device using the Quartus II software.

Reprogramming the Flash Memory

You can now use the Nios processor in the Cyclone device and the GERMS monitor to reprogram the flash memory by performing the following steps:

1. Connect the Console RS-232 serial connector to the host computer using a serial cable.
2. Open a Nios SDK Shell by choosing **Programs > Altera > Nios Development Kit <installed version> Nios SDK Shell** (Start menu). The default flash image file is located in the Nios SDK Shell default directory.
3. To download the flash file to the GERMS monitor executing on the board, type:

```
nios-run -x -r -p com1 default_board_image_cyclone_1c20.flash
```

This command assumes that you connected the serial cable to COM1 on your host computer. If you are using a different COM port, change the `com1` argument appropriately.

4. It will take 10 to 20 minutes to download the entire flash image. Do not reset the board during this time. When the download is complete, the Nios SDK Shell will return to a bash prompt.
5. Push the Force Safe button to perform a power-on reset and reconfigure the Cyclone device from flash memory. You should see the Safe LED turned on and activity on LEDs D0 — D7.

Your board is now re-configured to the default factory condition.

The default reference design shipped on the Nios development board implements a web server, among other functions. The Ethernet port provides a very fast and easy method to download hardware and software images to the board via a web browser on your host computer. The software reference design implements a web server on the Ethernet port as soon as the board powers up and configures with the factory-programmed safe configuration. The web server responds to any HTTP requests, regardless of origin, that arrive on its Ethernet connection.

This section assumes that you are familiar with the Nios SDK shell, the `nios-run` utility for serial communication with the Nios development board, and the GERMS monitor.




See the *Nios Embedded Processor Software Development Reference Manual* for information on these topics.

Connecting the Ethernet Cable

The Nios Development Kit includes an Ethernet (RJ45) cable and a male/female RJ45 crossover adapter. Before you connect these components, you must decide how you want to use the network features of your board. Select one of the two following connection methods:


1. *Point-to-Point Connection* — To use your Nios Development Board connected directly to a host computer point-to-point (not on a LAN), do the following:
 - a. Connect one end of your RJ45 cable to the female socket in the crossover adapter.
 - b. Insert the male end of the crossover adapter into RJ1 on the Nios Development Board.
 - c. Connect the other end of the RJ45 connector directly to the network (Ethernet) port on your host computer (see [Figure 25](#)).

Figure 25. Point-to-Point Connection

2. *LAN Connection* — To use your Nios development board on a LAN (for example, connecting to an Ethernet hub) do the following:
 - a. Connect one end of the RJ45 cable to the Ethernet connector on the development board (RJ1).
 - b. Connect the other end to your LAN connection (hub, router, wall plug, etc.).

Connecting the LCD Display

Your Nios Development Kit was delivered with a two-line x 16-character LCD text display. The web-server software displays useful status and progress messages on this display. If you wish to use the network features of the board, connect the LCD display to the Expansion Prototype Header J12 as shown in [Figure 26](#) (take special care of the location of pin 1).

Figure 26. Expansion Prototype Header - J12

Obtaining an IP address: DHCP

In order to function on a network (either a point-to-point or LAN), your board must have an IP address. Upon reset, the web-server will attempt to acquire an IP address via the DHCP protocol. Many LANs support DHCP.



If you do not know whether or not your LAN supports DHCP, it's probably best to try DHCP first.

The board will continue to attempt DHCP self-configuration for one full minute. You can tell whether DHCP has succeeded, or is still in progress, by reading status-messages on the LCD display. If your LAN does not support DHCP, or if you are using the point-to-point option above, then DHCP configuration will ultimately fail.

You can stop the DHCP process at any time by pressing push button switch SW3. Sending an exclamation point (!) to the board on the console serial port will also immediately terminate DHCP configuration.

If DHCP succeeds, the board will display a success message on the LCD display. It will also continuously display its IP address.

If DHCP fails (or is aborted), the board will obtain its IP address from flash memory. All boards are delivered from the factory with the IP address 10.0.0.51. You can change the IP address using commands sent via the console serial port (see [“IP Addresses for Point-to-Point Connections”](#) below).

IP Addresses for Point-to-Point Connections

Your host computer and the development board are the only two devices connected to a very simple (one-wire) network. When the board is delivered from the factory, it is pre-programmed with the default IP address 10.0.0.51. (The 10.0.0.x subnet is conventionally reserved for development, testing, and prototyping.) For most operating systems, it will be necessary to assign your host computer an IP address on this same subnet.

For example, the address 10.0.0.1 will work fine. Your computer and your development board are the only two devices connected on this simple network, so it is not necessary to get an address assigned to you by your system administrator. Any address in the 10.0.0.x subnet will work and there is no possibility of conflicting with another device on the network. You do, however, need the ability to change the IP address of your host computer. On Windows machines, this is accomplished through the **Network Connections** control panel.

Upon reset, the board will power-up and attempt DHCP self-configuration. On a point-to-point network, you should abort DHCP by pressing SW3. If you frequently use your board in a point-to-point configuration, you may wish to disable DHCP entirely by typing the command: `xdhcp : off` to the console serial port.

IP Addresses for LAN Connections

If your LAN does not support DHCP, or if DHCP self configuration failed, then you will need to assign your board a fixed IP address before you can access it over a network. All boards arrive with a default IP address of 10.0.0.51. (The 10.0.0.x subnet is conventionally reserved for development, test, and prototyping.) You need to obtain a safe IP address in your LAN's subnet from your system administrator.

Once you have obtained a safe IP address, you can assign it to your board using GERMS commands over the serial connection. The GERMS monitor in the default software reference design has been extended to implement the `xip` command. The `xip` command sets the IP address for your board, and saves this address in flash memory. In general, you will only need to assign an IP address to your board once. However, you may change it at any time by issuing another `xip` command.

For example, to assign the IP address 137.57.136.165, you would type the following command at the GERMS + prompt:

```
xip:137.57.136.165 (no spaces)
```



The GERMS monitor does not recognize the Backspace key or Delete key. If you make a mistake typing, press the Escape key to get a fresh GERMS prompt and re-enter the command. To read back the IP address, you can use the `xip` command with no colon or arguments. To activate the new IP address, you must reset your board by pushing the Force Safe button or the Reset, Config button.

Browsing your Board

Once your board has a valid IP address (obtained from either DHCP self configuration or from flash memory), you can access the board via a web browser (e.g., Microsoft Internet Explorer). The board serves a website which includes both extensive documentation and useful network-download utility functions. To browse this site, open a web browser and type the IP address of the board (four numbers separated by decimal-points) as a URL directly into the browser's **Address** input field. You can determine your board's IP address by reading the messages displayed on the LCD display (the IP address is continuously displayed) or by typing `xip` on the Console Serial Port.



Extensive additional information on the board's network communications and download utilities are available via this web interface.

A

- Appendix A
 - Shared bus table 39
- Appendix B
 - Restore the factory configuration 43
- Appendix C
 - Board Ethernet connection 45

B

- Block diagram 11
- Board Ethernet connection
 - Browse the board 48
 - Connecting the Ethernet cable 45
 - Connecting the LCD display 46
 - Obtaining an IP address - DHCP 46
 - LAN connections 48
 - Point-to-point connections 47

C

- Clock circuitry 35
- Compact flash connector 14
- Configuration and reset buttons 33
 - SW10 - Reset config 34
 - SW8 - CPU reset 34
 - SW9 - Safe config 34
- Configuration controller device 28
 - Configuration data 29
 - Configuration-status LEDs 33
 - Cyclone configuration 28
 - Reset distribution 28
 - Safe and user configurations 30
 - Starting configuration 28
- Configuration-status LEDs
 - Indicators 33
- Conventional flash memory usage 30
- Cyclone EP1C20 device 13

D

- Development board
 - Component illustration 12
 - Features 9
 - General description 9
- Dual 7-segment display 26
 - U8 & U9 pin information 26
- Dual SRAM devices 18

E

- Ethernet PHY/MAC 19
- Expansion connector header (PROTO1) 19
 - J11 pin information 20
 - J12 pin information 21
 - J13 pin information 21
- Expansion connector header (PROTO2) 21
 - J15 pin information 23
 - J16 pin information 22
 - J17 pin out information 23

F

- Flash memory allocation 31
- Flash memory device 13

I

- Individual LEDs (D0 - D7) 27
 - Pin information 27

J

- JTAG connections 36
 - JTAG to Cyclone device (J24) 36
 - JTAG to MAX device (J5) 38

M

- Mictor connector 23
 - Debug port to OCI debug module 24
 - J25 pin information 25

P

- Power-supply circuitry 35
- Push-button switches 26
 - pin information 26

R

- Reference design
 - default 9
 - restoring 10
- Restore factory configuration
 - Configuring the Cyclone device 43
 - Reprogramming flash memory 44

S

- Schematics 12
- SDRAM device 16
- Serial configuration device 27
- Serial flash connector 27
- Serial port connectors 25
 - Console
 - J19 pin information 25
 - Debug
 - J27 pin information 26
- SRAM devices 18
- SW10 button 34
- SW8 button 34
- SW9 button 34