



# LeonardoSpectrum–Altera Software Installation Instructions

September 2000, ver. 1.0

## Before You Install

Before you install the LeonardoSpectrum synthesis tool, you must have both the LeonardoSpectrum self-extracting executable file (**ls\_install.exe**) and a license file (**license.dat**). You can obtain both the software and license file from this web site. You can use the LeonardoSpectrum software on PCs running Windows 95/98/NT 4.0.

If you have a question or problem that is not answered by the information provided here, please email Altera Applications with a detailed description of your problem at [support@altera.com](mailto:support@altera.com).

## Installing the Software

To install the software, perform the following steps (you may wish to print out these instructions):

1. Run the self-extracting file **ls\_oem\_1999\_1j\_pc.exe**. Save the installation program to your hard drive.
2. Run the installation program **ls\_install.exe**. Follow the on-screen instructions.
3. To complete your installation, you must specify your license file.

Please note that the software installation directory path must not contain spaces.