


SEALEVEL[®]

SYSTEMS INCORPORATED

Route 56[®]

USER MANUAL



Part # 5011

Sealevel Systems, Inc
155 Technology Place
P.O. Box 830
Liberty, SC 29657 USA

Phone: (864) 843-4343
FAX: (864) 843-3067
www.sealevel.com

Contents

INTRODUCTION	1
OVERVIEW	1
WHAT'S INCLUDED.....	1
FACTORY DEFAULT SETTINGS.....	1
CARD SETUP.....	2
ADDRESS SELECTION.....	2
INTERFACE SELECTION	3
IRQ Selection.....	4
INSTALLATION.....	5
TECHNICAL DESCRIPTION	6
FEATURES	6
IUSC™.....	7
RAM.....	7
CONTROL / STATUS REGISTERS DEFINITION.....	8
Description	9
I/O SIGNAL DERIVATION	10
25 PIN CONNECTOR SIGNAL LAYOUTS (DB-25 MALE).....	11
RS-232 Signals	11
V.35 Signals	11
V.35 Signals (continued)	12
RS-530 (RS-422)	12
RS-530A.....	12
RS-485 or RS-485T.....	13
SPECIFICATIONS.....	14
ENVIRONMENTAL SPECIFICATIONS.....	14
POWER CONSUMPTION	14
MEAN TIME BETWEEN FAILURES (MTBF)	14
PHYSICAL DIMENSIONS.....	14
APPENDIX A - TROUBLESHOOTING.....	15
APPENDIX B - HOW TO GET ASSISTANCE.....	16
APPENDIX C - ELECTRICAL INTERFACE.....	17
RS-232.....	17
RS-422.....	17
RS-530 / 530A.....	18
V.35.....	18

APPENDIX D - SILK-SCREEN.....	19
APPENDIX E - COMPLIANCE NOTICES.....	20
FEDERAL COMMUNICATIONS COMMISSION STATEMENT.....	20
EMC DIRECTIVE STATEMENT	20
WARRANTY	21

Figures

FIGURE 1 - ADDRESS SELECTION TABLE.....	2
FIGURE 2 - DIP-SWITCH ILLUSTRATION.....	2
FIGURE 3 – HEADER E1 IRQ SELECTION.....	4

© 1999f Sealevel Systems, Incorporated. All rights reserved.

Introduction

Overview

The **ROUTE 56** adapter provides the PC with a single channel high-speed multi-protocol serial interface suitable for the most popular communication protocols. This sync/async card provides an ideal solution for high-speed applications including LAN/WAN connectivity. Utilizing the Z16C32 (IUSC™) on chip DMA controller eliminates bus bandwidth constraints that are placed on typical PC interface adapters, allowing data rates to reach 10M bps in burst mode. By utilizing the Z16C32's 32 byte FIFO buffer coupled with 256K of on board memory, higher data rates are achieved without increasing processor overhead.

What's Included

The **ROUTE 56** is shipped with the following items. If any of these items are missing or damaged, contact the supplier.

- **ROUTE 56** Adapter
- **ROUTE 56** Developers Toolkit Software
- **ROUTE 56** User manual

Factory Default Settings

The **ROUTE 56** factory default settings are as follows:

Base Address	IRQ	Default Electrical Interface
300	5	RS-530/422

To install the **ROUTE 56** using factory default settings, refer to Installation on page 5.

For your reference, record installed **ROUTE 56** settings below:

Base Address	IRQ	Default Electrical Interface

Card Setup

The **ROUTE 56** contains several jumper straps for each port, which must be set for proper operation.

Address Selection

The **ROUTE 56** adapter occupies a total of eight consecutive I/O locations. A DIP-switch is used to set the base address for these locations. Be careful when selecting the base address as some selections conflict with existing PC ports. The following table shows several examples that usually do not cause a conflict.

Address Hex	Binary			Switch Settings					
	A9	A8	A0	1	2	3	4	5	6
238-23F	1	000111XXX		On	On	On	Off	Off	Off
300-307	1	100000XXX		Off	On	On	On	On	On
308-30F	1	100000XXX		Off	On	On	On	On	On
310-317	1	100010XXX		Off	On	On	On	Off	On
318-31F	1	100010XXX		Off	On	On	On	Off	On
320-327	1	100100XXX		Off	On	On	Off	On	On
3A0-3A7	1	110100XXX		Off	Off	On	Off	On	On

Figure 1 - Address Selection Table

The following illustration shows the correlation between the DIP-switch setting and the address bits used to determine the base address. Assume 300 Hex to 307 Hex is the desired base address. 300 Hex = (1) 1 0000 0X in Binary.





Figure 2 - DIP-Switch Illustration

Note: Setting the switch “On” or “Closed” corresponds to a “0” in the address, while leaving it “Off” or “Open” corresponds to a “1”.

Interface Selection

The *Route 56* supports a variety of electrical interfaces. These interfaces may be selected in two ways. The determining bit is found at Base+5, bit position D4, and is identified as IFSEL (InterFace SElect). Reference the **Control/Status Register Descriptions**, found in the **Technical Description** section of this manual for this bit description. When IFSEL = 0, then the values read from M3-M0 are determined by the DIP-switch SW2. If all the switches on SW2 are off, then all drivers and receivers are in a high impedance state. Only one switch should be set to the on position at a time. The following example illustrates SW-2:



When IFSEL = 1, then the values read from M3-M0 are determined by values written to base+5 register. If this method is utilized, all switches on SW2 should be set in the off position, unless a default value is required. This prevents the application of excess voltages on power-up to external receivers. The following table shows the valid options.

HEX	M3	M2	M1	M0	INTERFACE MODE
0	0	0	0	0	all signals are high impedance
1	0	0	0	1	* not supported *
2	0	0	1	0	RS-232
3	0	0	1	1	* not supported *
4	0	1	0	0	RS-485 with 120 ohm termination
5	0	1	0	1	RS-485 without termination
6,7,8,9	0	1	1	0	* not supported *
A	1	0	1	0	single ended loop-back
B	1	0	1	1	differential loop-back
C	1	1	0	0	* not supported *
D	1	1	0	1	RS-530
E	1	1	1	0	V.35
F	1	1	1	1	RS-530A

IRQ Selection

Header E1 is used to select the interrupt request for each the *Route 56*. In the example below, IRQ12 is selected. This setting must be made prior to installing the adapter. Please query your system to determine the best available IRQ to use.




Figure 3 – Header E1 IRQ Selection

Installation

The **ROUTE 56** can be installed in any of the 16-bit ISA expansion slots. The **ROUTE 56** contains several jumper straps for each port, which must be set for proper operation.

1. Turn off PC power. Disconnect the power cord.
2. Remove the PC case cover.
3. Locate an available slot and remove the blank metal slot cover.
4. Gently insert the **ROUTE 56** into the slot. Make sure the adapter is seated properly.
5. Replace the screw.
6. Replace the cover.
7. Connect the power cord.

Installation is complete.

The **ROUTE 56** has a number of cabling options available. These options include:

- **CA-103** - This cable provides a high quality shielded cable with the V.35 mechanical specification met on one end and a DB-25S (female) on the other end. V.35 has a mechanical specification that is impossible to place on a PC bracket and requires this adapter cable.
- **CA-104** - This cable provides a 6' extension for use with RS-232, and RS-530.
- **CA-107** - RS-530 (DB-25P) to RS-449 (DB-37P) cabling adapter. RS-530 is replacing RS-449 in Telecom applications, but there is still a very large base of installed equipment that uses the RS-449 pin-out. Both standards use RS-422 to define the electrical specifications and are interchangeable via this adapter cable.

Note: DSR is not available on the card as shipped but can be enabled by placing a 0-ohm resistor at R30 and removing the 0-ohm resistor at R31. This will disable the use of Ring Indicator on RS-232, V.35, and RS-530A.

Operation System Installation

Windows NT Users Only

Select **Install Software** at the beginning of the CD and follow the instructions for installing the **HDLC C32** driver located under **Synchronous/Asynchronous** software installation selection.

Technical Description

The Sealevel Systems **ROUTE 56** adapter was designed for seamless integration into any ISA based system. The **ROUTE 56** adapter requires a 80286 or higher CPU, one IRQ, a 8 byte block of I/O address and a 16K block of memory address. The memory range of this adapter is configured to reside in the lower 1-Megabyte of memory and appears to the system as a bank switched 16K window. The **ROUTE 56** adapter's memory range can be disabled allowing multiple adapters to share the same block of memory.

Features


- Single channel high speed sync/async wide area network (WAN) interface
- RS-232, RS-422/449, EIA-530, V.35 and RS-485 serial interface capability with versatile cabling options
- Multi-protocol capable including: PPP (point-to-point protocol), Frame Relay, X.25, high-speed Async, Bi-Sync, Mono-Sync, HDLC, SDLC
- Ideal for T1, Fractional T1, E1, and ISDN applications
- On-board Z16C32 (IUSC™) with built in DMA controller and 32 byte FIFO buffer
- Up to 10 Mbps burst mode
- 256K of on-board RAM
- Link list DMA supported
- 16-bit data path
- Off loads communication processing
- OEM Security Feature available

IUSC™

The **ROUTE 56** adapter is based on a single Zilog Z16C32 IUSC (Integrated Universal Serial Controller). Application and driver software access the IUSC registers through the first 256 bytes of on-board RAM. Register access to the IUSC can be disabled via I/O registers allowing the first 256 bytes of RAM to be used for buffer storage. The IUSC has a built-in DMA controller that allows high-speed data transfers directly to and from the 256K block of on-board memory. The IUSC's built-in DMA controller supports 4 different modes of DMA transfer: Single Buffer, Pipelined, Array, and Link List. An on-board 16MHz oscillator clocks the IUSC.

RAM

The **ROUTE 56** has 256K of on-board SRAM. The 256K bytes of SRAM appear to the host processor in the 2nd 512K bytes of the host's memory address range, (Segment 80000 to F0000). This 256K of SRAM is in a 16K bank-switched window. The address of the 16K window and the page is software selectable. The IUSC always views the 256K of SRAM as linear memory. The SRAM can be selectively disabled through software. The SRAM should be addressed in a section that does not conflict with system memory (i.e. I/O adapters, Video Memory, BIOS/BIOS extensions.)



Control / Status Registers Definition

The I/O register base address is selected by SW1. The address range is 200H to 3FFH. The control / status registers occupies 8 consecutive locations. The following tables provide a functional description of the bit positions.

X = do not care { } = always this value

Address	Mode	D7	D6	D5	D4	D3	D2	D1	D0
Base+0	RD	MEMEN	IUSCEN	{0}	{0}	P17	P16	P15	P14
Base+0	WR	MEMEN	IUSCEN	X	X	P17	P16	P15	P14
Base+1	RD	{0}	{0}	{0}	MA18	MA17	MA16	MA15	MA14
Base+1	WR	INT2	INT1	INT0	MA18	MA17	MA16	MA15	MA14
Base+2	RD	{0}	WSEN	{1}	{0}	{0}	{0}	{0}	{0}
Base+2	WR	X	WSEN	X	X	X	X	X	X
Base+3	RD	{0}	{0}	INTPEND	RESTAT	{1}	{0}	{0}	{0}
Base+3	WR	Software board reset	X	X	X	X	X	X	X
Base+4	RD	SHARE	IRQEN	{0}	{0}	{0}	{0}	{0}	{0}
Base+4	WR	SHARE	X	X	X	X	X	X	X
Base+5	RD	LL	RL	{0}	IFSEL	M3	M2	M1	M0
Base+5	WR	LL	RL	X	IFSEL	M3	M2	M1	M0
Base+6	RD	SD7	SD6	SD5	SD4	SD3	SD2	SD1	SD0
Base+7	RD	SD15	SD14	SD13	SD12	SD11	SD10	SD9	SD8

Technical Description

Field	Description
MEMEN	1 = Host access to RAM or IUSC enabled; 0 = Host access to RAM or IUSC disabled.
IUSCEN	1 = Enable Host access to RAM; 0 = Enable Host access to IUSC.
P17-P14	These bits select which of sixteen 16K ram pages is visible at the address selected by MA18-MA14.
MA18-14	These bits select the base memory address of the 16K bank-switched window of the 256K SRAM.
INT2-INT0	Interrupt: 000 = Interrupts disabled, Interrupts enabled for all other values 001-111.
IRQEN	1 = Interrupts enabled, 0 = Interrupts disabled (Status Bit, Read Only)
SHARE	1= IRQ sharing enabled ;0= IRQ sharing disabled. (0 on power up)
INTPEND	IUSC interrupt status: 1 = No interrupt pending on IUSC; 0 = Interrupt pending on IUSC.
RESTAT	Reset status: 1 = On-board reset inactive; 0 = On-board reset active.
WSEN	Wait State Enable: 1 = disable wait states (Zero wait states); 0 = enable wait states. (0 on power up)
RL	Remote loopback
LL	Local loopback
IFSEL	0 = DIP-switch interface select, 1 = Base+5 register M3-M0 interface select. (0 on power up)
M0-M3	I/O mode select to SP505 If IFSEL = 0, the value read is equal to the switch setting If IFSEL = 1, the value read is the value written See table for valid interface options
SD0-SD15	Optional security feature. Unique value per customer or application. (default value = FFFF)

I/O Signal Derivation

The *Route 56* input/output signals are directly generated via the Zilog 16C32 IUSC. The following table defines these signals, their origin pin and signal name following the conventions set by the 16C32 user's manual. If using a Sealevel Systems, Inc. supplied driver, this is for informational use only.

Signal	Source
Transmit Data	16C32 TXD Pin
Request To Send	16C32 Port7 Pin
Data Terminal Ready	16C32 Port6 Pin
Transmit Signal Element Timing	16C32 TXC Pin
Receive Data	16C32 RXC Pin
Clear To Send	16C32 CTS Pin
Data Set Ready	16C32 RXREQ Pin
Data Carrier Detect	16C32 DCD Pin
Transmit Clock	16C32 TXCO Pin
Receive Clock	16C32 RXCO Pin
Ring Indicator	16C32 TXREQ Pin

25 Pin Connector Signal Layouts (DB-25 Male)

RS-232 Signals

Dip-Switch SW2-1 or Base+5, M3-M0=2, 0010

Signal	Name	Pin #	Mode
GND	Ground	7	
RD	Receive Data	3	Input
CTS	Clear To Send	5	Input
DSR	Data Set Ready	6	Input
DCD	Data Carrier Detect	8	Input
TM	Test Mode	25	Input
RI	Ring Indicator	22	Input
TXC	Transmit Clock	15	Input
RXC	Receive Clock	17	Input
TSET	Transmit Signal Element Timing	24	Output
DTR	Data Terminal Ready	20	Output
TD	Transmit Data	2	Output
RTS	Request To Send	4	Output
LL	Local Loop-back	18	Output
RL	Remote Loop-back	21	Output

Technical Note: Please terminate any control signals that are not going to be used. The most common way to do this is connect RTS to CTS and RI. Also, connect DCD to DTR and DSR. Terminating these pins, if not used, will help insure you get the best performance from your adapter.

V.35 Signals

DIP-Switch SW2-6 or Base+5, M3-M0=E, 1110

Signal	Name	DB-25	V.35	Mode
GND	Ground	7	B	
RDB RX+	Receive Positive	16	T	Input
RDA RX-	Receive Negative	3	R	Input
TXCB TXC+	Transmit Clock Positive	12	AA	Input
TXCA TXC-	Transmit Clock Negative	15	Y	Input
RXCB RXC+	Receive Clock Positive	9	X	Input
RXCA RXC-	Receive Clock Negative	17	V	Input
TDB TX+	Transmit Positive	14	S	Output
TDA TX-	Transmit Negative	2	P	Output
TSETB TSET+	Transmit Signal Element Timing +	11	W	Output
TSETA TSET-	Transmit Signal Element Timing -	24	U	Output
CTS	Clear To Send	5	D	Input *
DSR	Data Set Ready	6	E	Input *

V.35 Signals (continued)

DCD	Data Carrier Detect	8	F	Input *
RI	Ring Indicator	22	J	Input *
DTR	Data Terminal Ready	20	H	Output *
RTS	Request To Send	4	C	Output *
LL	Local Loop-back	18		Output *
RL	Remote Loop-back	21		Output.*

* **Note:** All modem control signals are single ended (un-balanced) with RS-232 signal levels.

RS-530 (RS-422)

DIP-Switch SW2-2 or Base+5, M3-M0=D, 1101

Signal	Name	Pin #	Mode
GND	Ground	7	
RDB RX+	Receive Positive	16	Input
RDA RX-	Receive Negative	3	Input
CTSB CTS+	Clear To Send Positive	13	Input
CTSA CTS-	Clear To Send Negative	5	Input
DCDB DCD+	Data Carrier Detect Positive	10	Input
DCDA DCD-	Data Carrier Detect Negative	8	Input
TXCB TXC+	Transmit Clock Positive	12	Input
TXCA TXC-	Transmit Clock Negative	15	Input
RXCB RXC+	Receive Clock Positive	9	Input
RXCA RXC-	Receive Clock Negative	17	Input
TDB TX+	Transmit Positive	14	Output
TDA TX-	Transmit Negative	2	Output
RTSB RTS+	Request To Send Positive	19	Output
RTSA RTS-	Request To Send Negative	4	Output
DTRB DTR+	Data Terminal Ready Positive	23	Output
DTRA DTR-	Data Terminal Ready Negative	20	Output
TSETB TSET+	Transmit Signal Element Timing Positive	11	Output
TSETA TSET-	Transmit Signal Element Timing Negative	24	Output

DSR is not available on the card as shipped but can be enabled by placing a 0-ohm resistor at R30 and removing the 0-ohm resistor at R31. This will disable the use of Ring Indicator on RS-232, V.35, and RS-530A. In this mode the following signals are supported.

DSRB DSR+	Data Set Ready Positive	22	Input
DSRA DSR-	Data Set Ready Negative	6	Input

RS-530A

DIP-Switch SW2-3 or Base+5, M3-M0=F, 1111

Signal	Name	Pin #	Mode
GND	Ground	7	
RDB RX+	Receive Positive	16	Input
RDA RX-	Receive Negative	3	Input
CTSA CTS-	Clear To Send Negative	5	Input
DCDA DCD-	Data Carrier Detect Negative	8	Input
RIA	Ring Indicator Negative	22	Input
TXCB TXC+	Transmit Clock Positive	12	Input
TXCA TXC-	Transmit Clock Negative	15	Input
RXCB RXC+	Receive Clock Positive	9	Input
RXCA RXC-	Receive Clock Negative	17	Input
TDB TX+	Transmit Positive	14	Output
TDA TX-	Transmit Negative	2	Output
RTSA RTS-	Request To Send Negative	4	Output
DTRA DTR-	Data Terminal Ready Negative	20	Output
TSETB TSET+	Transmit Signal Element Timing Positive	11	Output
TSETA TSET-	Transmit Signal Element Timing Negative	24	Output
LL	Local Loop-back	18	Output
RL	Remote Loop-back	21	Output

RS-485 or RS-485T

RS-485T DIP-Switch SW2-4 or Base+5, M3-M0=4, 0100

RS-485T DIP-Switch SW2-5 or Base+5, M3-M0=4, 0101

Signal	Name	Pin #	Mode
GND	Ground	7	
RDB RX+	Receive Positive	16	Input
RDA RX-	Receive Negative	3	Input
TXCB TXC+	Transmit Clock Positive	12	Input
TXCA TXC-	Transmit Clock Negative	15	Input
RXCB RXC+	Receive Clock Positive	9	Input
RXCA RXC-	Receive Clock Negative	17	Input
TDB TX+	Transmit Positive	14	Output
TDA TX-	Transmit Negative	2	Output
TSETB TSET+	Transmit Signal Element Timing Positive	11	Output
TSETA TSET-	Transmit Signal Element Timing Negative	24	Output
LL	Local Loop-back	18	Output
RL	Remote Loop-back	21	Output

Specifications

Environmental Specifications

Specification	Operating	Storage
Temperature Range	0 to 50 ° C (32 to 122 ° F)	-20 to 70 ° C (-4 to 158 °F)
Humidity Range	10 - 90% R.H. Non Condensing	10 - 90% R.H. Non Condensing

Power Consumption

Supply line	+5 VDC
Rating	500mA

Mean Time Between Failures (MTBF)

Greater than 150,000 hours. (Calculated)

Physical Dimensions

Board length	6.095 inches	(15.4813 cm.)
Board Height including Goldfingers	3.40 inches	(8.636 cm.)
Board Height excluding Goldfingers	3.10 inches	(7.874 cm.)

Appendix A - Troubleshooting

The Developers Toolkit Software is supplied with the Sealevel Systems adapter and will be used in the troubleshooting procedures. Using this software and following these simple steps can eliminate most common problems without the need to call Technical Support.

1. Identify all I/O adapters currently installed in your system. This includes your on-board serial ports, controller cards, sound cards etc. The I/O addresses used by these adapters, as well as the IRQ (if any) should be identified.
2. Configure your Sealevel Systems adapter so that there is no conflict with currently installed adapters. No two adapters can occupy the same I/O address.
3. Make sure the Sealevel Systems adapter is using a unique IRQ. While the Sealevel Systems adapter does allow the sharing of IRQs, many other adapters (i.e. SCSI adapters and on-board serial ports) do not. The IRQ is typically selected via an on-board header block. Refer to the section on Card Setup and the Control/Status port for help in choosing an I/O address and IRQ.
4. Make sure the Sealevel Systems adapter is securely installed in a 16-bit slot.
5. Use the supplied software and User Manual to verify that the Sealevel Systems adapter is configured correctly. The supplied software contains a diagnostic program "SSDR56" that will verify if an adapter is configured properly. This diagnostic program is written with the user in mind and is easy to use. Refer to the "README.txt" file on the supplied software for detailed instructions on using "SSDR56".
6. The following are known I/O conflicts:
 - The 278 and 378 settings may conflict with your printer I/O adapter.
 - 3B0 cannot be used if a Monochrome adapter is installed.
 - 3F8-3FF is typically reserved for COM1:
 - 2F8-2FF is typically reserved for COM2:
 - 3E8-3EF is typically reserved for COM3:
 - 2E8-2EF is typically reserved for COM4:

Appendix B - How To Get Assistance

Please refer to Appendix A - Troubleshooting prior to calling Technical Support.

1. Read this manual thoroughly before attempting to install the adapter in your system.
2. When calling for technical assistance, please have your user manual and current adapter settings. If possible, please have the adapter installed in a computer ready to run diagnostics.
3. Sealevel Systems maintains a Home page on the Internet. Our home page address is www.sealevel.com. The latest software updates, and newest manuals are available via our FTP site that can be accessed from our home page.
4. Technical support is available Monday to Friday from 8:00 a.m. to 5:00 p.m. eastern time. Technical support can be reached at (864) 843-4343.

RETURN AUTHORIZATION MUST BE OBTAINED FROM SEALEVEL SYSTEMS BEFORE RETURNED MERCHANDISE WILL BE ACCEPTED. AUTHORIZATION CAN BE OBTAINED BY CALLING SEALEVEL SYSTEMS AND REQUESTING A RETURN MERCHANDISE AUTHORIZATION (RMA) NUMBER.

Appendix C - Electrical Interface

RS-232

Quite possibly the most widely used communication standard is RS-232. This implementation has been defined and revised several times and is often referred to as RS-232 or EIA/TIA-232. It is defined by the EIA as the *Interface between Data Terminal Equipment and Data Circuit-Terminating Equipment Employing Serial Binary Data Interchange*. The mechanical implementation of RS-232 is on a 25 pin D sub connector. RS-232 is capable of operating at data rates up to 20 Kbps at distances less than 50 ft. The absolute maximum data rate may vary due to line conditions and cable lengths. RS-232 often operates at 38.4 Kbps over very short distances. The voltage levels defined by RS-232 range from -12 to +12 volts. RS-232 is a single ended or unbalanced interface, meaning that a single electrical signal is compared to a common signal (ground) to determine binary logic states. A voltage of +12 volts (usually +3 to +10 volts) represents a binary 0 (space) and -12 volts (-3 to -10 volts) denotes a binary 1 (mark). The RS-232 and the EIA/TIA-574 specification defines two type of interface circuits, Data Terminal Equipment (DTE) and Data Circuit-Terminating Equipment (DCE). The Sealevel Systems adapter is a DTE interface.

RS-422

The RS-422 specification defines the electrical characteristics of balanced voltage digital interface circuits. RS-422 is a differential interface that defines voltage levels and driver/receiver electrical specifications. On a differential interface, logic levels are defined by the difference in voltage between a pair of outputs or inputs. In contrast, a single ended interface, for example RS-232, defines the logic levels as the difference in voltage between a single signal and a common ground connection. Differential interfaces are typically more immune to noise or voltage spikes that may occur on the communication lines. Differential interfaces also have greater drive capabilities that allow for longer cable lengths. RS-422 is rated up to 10 Megabits per second and can have cabling 4000 feet long. RS-422 also defines driver and receiver electrical characteristics that will allow 1 driver and up to 32 receivers on the line at once. RS-422 signal levels range from 0 to +5 volts. RS-422 does not define a physical connector.


RS-530 / 530A

RS-530 (a.k.a. EIA-530) compatibility means that RS-422 signal levels are met, and the pin-out for the DB-25 connector is specified. The EIA (Electronic Industry Association) created the RS-530 specification to detail the pin-out, and define a full set of modem control signals that can be used for regulating flow control and line status. The major difference between RS-530 and RS-530A lies in the modem control interface signals. In RS-530 the signals are differential, in RS-530A the signals are single ended. The RS-530 specification defines two types of interface circuits, Data Terminal Equipment (DTE) and Data Circuit-Terminating Equipment (DCE). The Sealevel Systems adapter is a DTE interface.

V.35

V.35 is a standard defined by ITU (formerly CCITT) that specifies an electrical, mechanical, and physical interface that is used extensively by high-speed digital carriers such as AT&T Dataphone Digital Service (DDS). ITU V.35 is an international standard that is often referred to as *Data Transmission at 48 Kbps Using 60 - 108 KHz Group-Band Circuits*. ITU V.35 electrical characteristics are a combination of unbalanced voltage and balanced current mode signals. Data and clock signals are balanced current mode circuits. These circuits typically have voltage levels from 0.5 Volts to -0.5 Volts (1 Volt differential). The modem control signals are unbalanced signals and are compatible with RS-232. The physical connector is a 34 pin connector that supports 24 data, clock and control signals. The physical connector is defined in the ISO-2593 standard. ITU V.35 specification defines two type of interface circuits, Data Terminal Equipment (DTE) and Data Circuit-Terminating Equipment (DCE). The Sealevel Systems adapter is a DTE interface.

Appendix D - Silk-Screen



Appendix E - Compliance Notices

Federal Communications Commission Statement

FCC - This equipment has been tested and found to comply with the limits for Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in such case the user will be required to correct the interference at his own expense.

EMC Directive Statement



Products bearing the CE Label fulfill the requirements of the EMC directive (89/336/EEC) and of the low-voltage directive (73/23/EEC) issued by the European Commission.

To obey these directives, the following European standards must be met:

- **EN55022 Class A** - “Limits and methods of measurement of radio interference characteristics of information technology equipment”
- **EN55024**- ‘Information technology equipment Immunity characteristics Limits and methods of measurement.
- **EN60950 (IEC950)** - “Safety of information technology equipment, including electrical business equipment”

Warning

This is a Class A Product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Always use cabling provided with this product if possible. If no cable is provided or if an alternate cable is required, use high quality shielded cabling to maintain compliance with FCC/EMC directives.

Warranty

Sealevel Systems, Inc. provides a lifetime warranty for this product. Should this product fail to be in good working order at any time during this period, Sealevel Systems will, at its option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Sealevel Systems assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Sealevel Systems will not be liable for any claim made by any other related party.

RETURN AUTHORIZATION MUST BE OBTAINED FROM SEALEVEL SYSTEMS BEFORE RETURNED MERCHANDISE WILL BE ACCEPTED. AUTHORIZATION CAN BE OBTAINED BY CALLING SEALEVEL SYSTEMS AND REQUESTING A RETURN MERCHANDISE AUTHORIZATION (RMA) NUMBER.

Sealevel Systems, Incorporated
155 Technology Place
P.O. Box 830
Liberty, SC 29657 USA
(864) 843-4343 FAX: (864) 843-3067
www.sealevel.com
email: support@sealevel.com

Technical Support is available from 8 a.m. to 5 p.m. Eastern time.
Monday - Friday

Trademarks

Sealevel, Sealevel Software, and Sealevel Systems are registered trademarks
Sealevel Systems, Incorporated
ROUTE 56 is a registered trademark of Sealevel Systems, Incorporated.