SUPPORT | 864.843.4343 | support@sealevel.com

SEALEVEL SUPPORT My Cart | Request a Custom Quote | Subscribe to eNewsletter

Products | Support | Custom Solutions | Community | Company | Contact

Enter a search term.

Q

#### **SUPPORT CATEGORIES**

Manuals & Documentation (224)

Driver Downloads & Software (34)

FAQs (151)

**∨** Learning Center (106)

#### **Digital I/O Handbook** (6)

Catalogs & Brochures (14)

Customer Spotlights (10)

White Papers (16)

Magazine Article Reprints (11)

Tech Update with Jon Titus (14)

# THE DIGITAL I/O HANDBOOK - APPENDIX & GLOSSARY

★ / Learning Center / Digital I/O Handbook / The Digital I/O Handbook - Appendix & Glossary

Published: December 9, 2009 • Last Updated: August 11, 2017 • Author: Sealevel

Category: Digital I/O Handbook



#### The Digital I/O Handbook

A Practical Guide to Industrial Input & Dutput Applications

21 중 1

COM Solutions (2)

SeaLATCH Locking USB (1)

Application Examples (18)

General Information (15)

Glossary

# RECENTLY UPDATED ARTICLES



[ Software ] SealO Classic V5 – Windows



LIFETIME WARRANTY, RETURN & REPAIR POLICY



**Shipping Policy** 



**Privacy Policy** 



[ Software ] SeaMAC USB – Windows


### POPULAR ARTICLES



[ Software ] SeaCOM – Windows



[ Software ] SeaMAX – Windows



#### Digital I/O Explained

Renowned technical author Jon Titus and the President and CEO of Sealevel Systems, Tom O'Hanlan, clearly explain real-world digital input/output implementation from both a hardware and software perspective. Whether you are a practicing engineer or a student, *The Digital I/O Handbook* will provide helpful insight you will use again and again.

- Covers a wide range of devices including optically isolated inputs, relays, and sensors
- Shows many helpful circuit diagrams and drawings
- Includes software code examples
- Presents common problems and solutions
- Detailed glossary of common industry terms

"What I like most is its mix of hardware and software. Most pages have a <u>bit</u> of code plus a schematic. All code snippets are in C. This is a great introduction to the tough subject of tying a computer to the real world. It's the sort of quick-start of real value to people with no experience in the field." – Jack Ganssle, The Embedded Muse, January, 2005.



SeaCOM Software Overview



How to configure USB serial adapters in Linux



How to change asynchronous serial COM port assignments in Windows Device Manager You can purchase the *Digital I/O Handbook* for \$19.95 by clicking here. *The Digital I/O Handbook* is FREE with any qualifying Sealevel Digital I/O product purchase.

#### **Topics Covered**

# Appendix Glossary

# **Appendix**

#### Switch and Relay Configurations

When you look at the specifications for relays and mechanical switches, you'll find a variety of designations, such as DPST and 3C, associated with them. These designations describe electrical contacts and how they work. A basic on-off light <a href="mailto:switch">switch</a>, for example, controls one circuit (pole), and it provides a <a href="mailto:switch">switch</a> contact in only one position (throw). So, engineers call this a single-pole, single throw (SPST) <a href="mailto:switch">switch</a>. (See **Figure A-1** for contact configurations.)




Figure A-1

A single-pole <u>switch</u> may include an additional contact so it can turn off one device and then turn on another. This type of switch contains a set of single-pole, double-throw (SPDT)

contacts. The term "double-throw" refers to a <u>switch</u> that can make connections in either of its two positions. Note that the two circuits in an <u>SPDT switch</u> always share a common signal, or pole.

Switches may include electrically separate "gangs" made up of several poles that act in unison. A double-pole, double-throw (DPDT) <a href="mailto:switch">switch</a> provides two independent <a href="mailto:SPDT">SPDT</a> switches operated by a single actuator. A DPDT switch can control two *independent* and *isolated* circuits.

Switches can include many poles, although for more than two poles the nomenclature uses numeric designations. So a 4PDT <a href="mailto:switch">switch</a> comes with four independent and isolated poles, each with two contacts. A single actuator or <a href="mailto:switch">switch</a> handle moves all four sets of contacts simultaneously. Keep in mind, though, that just because a <a href="mailto:switch">switch</a> has several poles, an application need not use them all. An <a href="mailto:SPDT">SPDT</a> <a href="mailto:switch">switch</a>, for example, will work just as well a <a href="mailto:SPST">SPST</a> <a href="mailto:switch">switch</a> in a simple on-off circuit.

<u>Switch</u> nomenclature also may include designations for momentary switches; devices that either momentarily open (break) or close (make) a circuit. A pushbutton used with a doorbell operates as a normally-open <u>switch</u>. Pushing a normally-closed pushbutton on a lawnmower could open the ignition circuit to stop current from flowing to the sparkplug; in effect stopping the mower's gasoline engine. Momentary switches carry the designations **NO** for normally-open, or **NC** for normally-closed. Even momentary switches may come with various contact configurations, so you may encounter spring-loaded switches that offer contacts in DPDT arrangements, for example.

Electromechanical relays also provide a variety of contact configurations such as <u>SPST</u>, <u>DPDT</u>, 3PDT, and so on. But suppose you have a <u>relay</u> with an <u>SPST</u> contact. That simple designation doesn't indicate whether the <u>switch</u> contacts open or close when you <u>energize</u> the <u>relay</u>. You just can't tell how a relay's contacts operate without more information. Relay manufacturers

use a different shorthand to designate relay contacts and the action a relay causes.

So, although relays come with standard contact configurations, such as  $\underline{\mathsf{SPDT}}$  and  $\underline{\mathsf{DPDT}}$ , the industry uses letters A, B, C, and so on, to indicate contact arrangements.

A <u>relay</u> with A-type contacts provides an <u>SPST</u> <u>switch</u> that *closes* when a circuit energizes the relay.

If you want <u>SPST</u> contacts to *open* when a circuit energizes a <u>relay</u>, choose one with B-type contacts. You can think of A-type contacts as normally-open (**NO**) and B-type contacts as normally-closed (**NC**).

A <u>relay</u> with a <u>SPDT</u> set of contacts-probably the most common <u>relay</u> contact arrangement-carries the C notation. A <u>relay</u>'s contact diagram shows the contact arrangement and notes which contacts open or close when a circuit energizes the <u>relay</u>. You will find that information printed on the case of an enclosed relay or in accompanying data sheets.

Relays, like manual switches, can provide multiple sets of isolated contacts that operate simultaneously. So a relay designated 2A would provide two separate **NO** <u>SPST</u> contacts, and a 2C <u>relay</u> would supply the equivalent of DPDT contacts. You may find relays with other letters that designate specialized contact configurations. A set of D contacts, for example, closes one circuit before opening another, also known as a make-before-break operation.

#### Glossary

\* – When used as a suffix on a signal name, an asterisk indicates a logic 0 causes the named action to occur. An input labeled TEST\* requires a logic 0 to cause the TEST action to occur. *See also:* Negative Logic *and /*.

/ – When used as a prefix on a signal name, a forward slash indicates a logic 0 causes the named action to occur. An input labeled /RUN requires a logic 0 to cause a RUN action. See also: Negative Logic and \*.

<u>Active High</u> – A <u>digital</u> signal that represents active, on, or true when its <u>voltage</u> is higher than the other logic state (low). Active-high signals can range from a few volts DC to as high as 24V DC, depending on the logic family or devices in use.

<u>Active Low</u> – A <u>digital</u> signal that represents active, on, or true when its <u>voltage</u> is lower than the other logic state (high). Active-low signals can range from <u>digital ground</u> to a few tenths of a volt.

Analog – A type of signal that varies continuously (lighter to darker, 4 to 20 mA, and so on), as opposed to a digital signal that can exist in only one of two possible states.

Analog Ground – The location in a system that serves as a reference ground for all analog signals. Some circuits may combine analog ground and digital ground, but most circuits separate them to reduce noise and ground currents.

**AND** – A logical operation in which the result is true only when all inputs are true. *See:* Logical AND.

AND Gate – A circuit that performs an AND operation based on the state of its inputs.

<u>ASCII</u> – American Standard Code for Information Interchange, an 8-<u>bit binary</u> code that represents characters and symbols in the Roman (English) alphabet. <u>ASCII</u> includes codes that controlled older communication devices, thus the CRTL key on computer keyboards.

BCD - See: Binary Coded Decimal.

Binary – A numbering system that allows for only two states, usually 1 and 0.

Binary-Coded Decimal (BCD) – The encoding of decimal numbers as four-bit binary values from  $0000_2$  for 0, to  $1001_2$  for 9. BCD uses only 10 of the 16 4-bit combinations.

<u>Bit</u>-**Wise** – An operation, usually between two bytes or words, in which corresponding bits take part in an operation.

Boolean Logic – A form of mathematics named after George Boole (1815-1864) who devised formal expressions for AND, OR, and INVERT operations.

Blocking Diode – A diode, also called an isolation diode, that stops, or blocks, current from flowing through a circuit. Typically used in a battery circuit to prevent the reverse biasing of a battery by a more positive power supply.

<u>Buffer</u> – An output device that operates high-current or high-<u>voltage</u> devices. Some manufacturers produce drivers specifically to control devices such as stepper motors or displays. *See:* Driver.

Buffered - A signal that has passed through a buffer. See: Buffer.

<u>Bus</u> – A group of related electrical signals. 1. A control <u>bus</u>, an <u>address</u>, <u>bus</u>, a data <u>bus</u>, and so on. Some buses carry specific names, such as PCI <u>Bus</u> and Universal Serial <u>Bus</u> (USB). 2. A group of conductors that distribute power.

Capacitor - An electronic component that stores a charge and provides a reserve of power in a

circuit. Typically used to smooth variations in a power-supply's output <u>voltage</u>, and to provide power in the event of brief power failures.

<u>Carry Current</u> – The amount of current a <u>relay</u>'s contacts can safely conduct after the contacts close.

**Central Processing Unit** (CPU) – The decision-making part of a computer, usually found within a computer's microprocessor.

Chassis Ground – The ground point in a system, typically on a metal chassis, where signals connect to an <u>earth ground</u>. In most cases, a grounded chassis helps shield circuits from <u>EMI</u> and <u>RFI</u>, and provides a safety connection to <u>ground</u>. This type of <u>ground</u> should not <u>carry</u> current. *See also:* Analog Ground *and* Digital Ground.

Coil - The wire-wound electromagnetic core of a relay or solenoid. See also: Relay and Solenoid.

<u>Complement</u> – In logic, an operation in which a logic 1 becomes a logic 0, and vice versa. In binary numbers, the complement of 101100 = 010011.

CPU - See: Central Processing Unit.

**Current** – A measure of the amount of electron flow in a circuit, typically measured in amperes (A) or milliamperes (mA).

<u>Darlington Output</u> – A configuration of output transistors that can handle high currents. Usually found on the outputs of sensors or buffers that drive relays or solenoids.

Derate - A decrease in the rating of device characteristics, depending on operating conditions.

Digital – A system that uses discrete states to represent information.

<u>Digital Ground</u> – A common 0V ground reference for all <u>digital signals</u>. <u>Digital ground</u> and <u>analog ground</u> systems are usually wired separately to avoid introducing <u>digital</u> noise into the analog circuit.

Diode - An electronic component that lets current flow only in one direction.

<u>Driver</u> – 1. A <u>driver</u> circuit, or <u>buffer</u>, that operates high-current or high-<u>voltage</u> devices. 2. Driver software links application programs and specific I/O devices.

<u>Dry Contact</u> – 1. Metallic contacts in a <u>relay</u> or <u>switch</u> that mechanically touch to make a contact. 2. Contacts through which no current flows. *See:* Wet Contact.

Earth Ground – The ground point in a system that provides the lowest voltage-reference point, or ""earth."" An earth ground usually connects to a power-line ground, a ground rod, or in some cases, cold-water plumbing. An earth ground should not carry current.

**Electro Magnetic Interference** (EMI) – Energy induced into a circuit by radiated emissions. EMI may cause unpredictable results. *See:* RFI.

EMI – See: Electro Magnetic Interference.

Excitation Voltage - A voltage that powers a sensor or transducer.

Energize - To provide power to a device or circuit. Typically to power a relay coil, thus forcing

it to change the state of its contacts.

Flag – 1. An electronic device, usually with two possible states, that signals an external event to a computer. 2. An internal  $\underline{CPU}$  indicator that signals a condition such as register overflow or error. Sensed with software.

**Flip-Flop** – A bistable logic circuit that changes state due to an input event, generally a clock or pulse signal. A flip-flop remains in that state until the next input event causes it to ""flip"" or ""flop"" to its other state.

Form-A Relay - A relay that supplies normally-open (NO) SPST contacts.

**Form-B** Relay – A relay that supplies normally-closed (NC) SPST contacts.

**Form-C** Relay - A relay that supplies normally-open and normally-closed SPDT contacts.

<u>Gate</u> – A logic device that performs Boolean-logic operations.

Gated – A signal that is enabled, allowed to operate, or allowed to pass through a circuit depending on the state of a separate logic condition or signal.

Ground - A zero-volt reference point in a system. Provides the reference for all other voltages.

<u>High Impedance</u> – 1. A high <u>resistance</u> that reduces current flow. 2. A third state in special logic devices that "disconnects" them from a bus.

**High-Side** Switch - A switch that makes a connection directly to power at a higher voltage than that at the controlled load.

Impedance – Similar to resistance, an impedance represents the total opposition to the flow of current offered by a circuit. Impedance equals the vector sum of resistance and reactance, which is the complex resistance resulting from inductance and capacitance, not just pure resistance. Measured in ohms, and given the symbol, Z.

<u>Inrush Current</u> – A large charging current that flows into a <u>capacitor</u> or circuit when power is first applied.

Interposing Relay – A relay that isolates the circuit driving it, and switches a higher current or voltage than the driving circuit could provide. *See:* Relay.

Inverter - A logic device that complements the logic state of its input. See: Complement.

I/O - Input/output, as in I/O port. See: Port.

<u>Isolation</u> – A condition that separates circuits so no current can flow between them. Special devices such as opto-couplers provide a signal path between two circuits, but without current flow between them.

<u>Latch</u> – A logic circuit that takes a ""snapshot"" of information and saves it. Latches operate using an edge-triggered or a level-triggered control signal.

LED - See: Light-Emitting Diode.

**Light-Emitting** Diode (LED) – A diode that emits light when current passes through it (forward biased). LEDs provide white light as well as most colors. LEDs usually require an external current-limiting resistor.

<u>Logical AND</u> – A Boolean-logic operation that produces a true output only when all the function or circuit inputs exist in the true state.

Logical OR – A Boolean-logic operation that produces a false output only when all the function or circuit inputs exist in the false state.

<u>Logic Ground</u> – A <u>ground</u>-reference point in a circuit for all logic signals. Usually kept separate from other grounds in a system due to noise concerns.

<u>Low Impedance</u> – A low-<u>resistance</u> circuit that usually requires high current to drive it, as opposed to a high-impedance circuit.

**Low-Side** Switch – A switch that makes a connection directly to ground.

Mask Byte – A combination of 1's and 0's used in a bit-wise logical operation to set or clear individual bits. Masks can exist as any integer value, such as byte, word, long word, and so on.

NAND Gate – A circuit that performs a NOT-AND operation based on the state of its inputs. This gate performs an AND operation and inverts (NOTs) its output.

Negative Logic - A notation that indicates a logic 0 represents the active state for a signal.

**Non-**Buffered – An unbuffered signal that should not drive more than a few inputs within its logic family. *See:* Buffered.

NOR Gate – A circuit that performs a NOT-OR operation based on the state of its inputs. This gate performs an OR operation and inverts (NOTs) its output.

**Normally-Closed (NC)** – Relay or <u>switch</u> contacts that normally <u>form a complete low-resistance</u> path for current flow. In an unenergized relay, a set of closed contacts.

**Normally-Open (NO)** – Relay or switch contacts that normally do not make contact. In an unenergized relay, a set of open contacts.

**NOT** – The equivalent of an inversion operation, usually applied as part of another logic element or operation. *See:* Inverter.

NPN – A type of transistor often used as an on-off <u>switch</u> in electronic devices. An <u>NPN switch</u> usually sinks current from a higher potential through a device to ground.

Open Collector – A logic device or sensor that provides an output transistor with an unconnected collector. When turned on, this transistor sinks current to ground, but it cannot source any current. An open-collector output usually serves as a <a href="mailto:switch">switch</a> to ground.

Optical Coupler - See: Opto-Coupler.

Optical Isolator - See: Opto-Coupler.

Optical Isolation – The use of a light path to transfer a signal from a transmitter, usually a light emitting diode (LED), to a receiver, usually a phototransistor. This technique provides electrical isolation as a signal passes from one circuit to another.

**Opto-Coupler** – A device that uses light emissions to cause an isolated output stage to turn on. This device allows detection and sensing of potentially dangerous or high <u>voltage</u> signals, while providing isolation and protection to the circuitry sensing them.

Opto-Isolator - See: Opto-Coupler.

**OR** – A logical operation or circuit in which the result is false only when all inputs are false. *See:* Logical OR.

OR Gate - A circuit that performs an OR operation based on the state of its inputs.

Overload Protection – The capability to protect a circuit when current exceeds a predetermined value. Devices such as fuses or circuit breakers automatically disconnect a load when they sense an overcurrent.

<u>PNP</u> – A type of transistor often used as an on-off <u>switch</u> in electronic devices. A <u>PNP</u> <u>switch</u> usually sources current from a positive supply to a device at a lower potential.

<u>Port</u> – A collection of signals that go to or from a computer for the input or output of information. For example, an 8-bit input port or a serial port.

Positive Logic - A notation that indicates a logic 1 represents the active state for a signal.

**Pull-Down** Resistor – A resistor used to pull a logic input ""down"" to the low state, or logic-0 state, thus preventing a disconnected input from floating into an undetermined state.

**Pull-Up** Resistor – A resistor used to pull a logic input ""up"" to the high state, or logic-1 state, thus preventing a disconnected input from floating into an undetermined state.

**Radio Frequency Interference** (RFI) – Unwanted high-frequency signals, often generated by switching circuits, power supplies, computer cables, and oscillators.  $\overline{RFI}$  may interfere with the proper operation of other circuits.

Reed Relay – A small relay comprising two magnetic contacts within a sealed glass envelope. When energized, a <u>coil</u> around the envelope moves the contacts to make a low-<u>resistance</u> connection. *See:* Relay.

Relay – A device that opens or closes a circuit under control of a separate and isolated circuit. A mechanical relay uses a coil to actuate mechanical contacts. A solid state relay uses electronic devices to open or close circuit paths. Both types of relays isolate the controlling circuit from the circuit the relay controls.

Resistance – The total amount of opposition to current in a circuit. Resistance carries the units of ohms and the Greek symbol omega,  $\Omega$ . Resistance values may have units of kilohms,  $k\Omega$  or megohms  $M\Omega$ . See: Resistor.

Resistance **Temperature Detector** – A stable, linear temperature detector that provides a varying resistance in direct proportion to temperature changes.

Resistor – A device that opposes or limits current flow. Usually noted in schematic diagrams as R. *See:* Resistance.

RFI - See: Radio Frequency Interference.

RTD - See: Resistance Temperature Detector.

<u>Sensor</u> – A device that monitors or measures phenomena such as temperature, pressure, light intensity, weight, conductivity, and so on. Sensors may provide <u>digital</u> or <u>analog</u> output proportional to the phenomenon measured.

Single-Pole Double-Throw (SPDT) – A three-terminal switch or relay in which one central

terminal connects to either one of the other two terminals. This type of <u>switch</u> can alternately connect a signal to one of two devices.

**Single-Pole Single-Throw** (SPST) – A two-terminal <u>switch</u> or <u>relay</u> that can open or close one circuit.

Sink – The ability to allow current to flow through the circuit, usually to ground.

Snubber – A circuit that suppresses inductive ""kickback"" that may result when inductive loads switch off. Unless snubbed, the kickback voltage can harm the device that drives the load. See: Suppression Diode.

Solenoid – An electrical coil equipped with a magnetic core. Energizing the coil moves the core. Removing the current lets the solenoid core return to its normal position. Solenoids move levers, open valves, and so on.

**Solid State** Relay (SSR) – A solid state circuit that employs devices such as opto-couplers, transistors, and triacs to perform the function of a mechanical relay. *See:* Relay.

**Source** – The ability to provide current flow.

SPDT - See: Single-Pole Double-Throw.

SPST - See: Single-Pole Single-Throw.

SSR - See: Solid State Relay.

Supply Current - The total current that a circuit requires from a power supply.

Suppression Diode – A reverse-biased diode placed across a relay or solenoid coil. When the coil loses power, the diode provides a short circuit that quickly dissipates energy stored in the coil.

<u>Surge Current</u> – A high charging current that flows into a power supply filter <u>capacitor</u> or similar circuit as the power is first turned on. Similar to inrush current.

<u>Surge Suppressor</u> – A circuit that limits the effects of power surges. Devices such as metaloxide varistors (MOVs), zener diodes, and fuses provide this function.

<u>Switch</u> – An electronic or mechanical device that can connect one signal to a series of connections. Switches ideally have zero <u>impedance</u> when closed and infinite <u>impedance</u> when open.

Thermocouple – A temperature transducer made of two dissimilar metals welded together at one point to form a junction that, whenheated in a complete circuit, generates a small voltage proportional to the junction temperature.

Three State – An output from a logic device that can exist in one of three states; logic 0, logic 1, or a high-impedance (disconnected) state. This latter state allows multiple outputs to connect to one signal, effectively providing a "bus" that many signals can share. Three-state devices will provide an output-enable signal that either connects logic signals to the device's outputs, or places the outputs in a high-impedance state. (National Semiconductor owns the trademark, "tristate™," although the term finds common use among designers.)

**Transistor-Transistor-Logic** ( $\top \top \bot$ ) – The type of circuit used in the popular 7400 logic-device families.

<u>Transparent Latch</u> – A <u>latch</u> that passes signals from its inputs to its outputs as long as its Enable signal remains active—usually logic 1. When the Enable signal changes to its inactive state—usually a logic 0—the <u>latch</u> closes and then the outputs remain as they were when the Enable signal changed from logic 1 to logic 0. In effect, this IC acts like a small memory.

Triac - A semiconductor switch that can control devices powered by AC current.

<u>Truth Table</u> – A table that shows all possible input and output conditions for a logic element such as a <u>gate</u> or flip-flop. This table may show <u>binary</u> states as well as clock and signal transitions.

TTL - See: Transistor-Transistor-Logic.

VA – *See:* Volt-Ampere.

 $\underline{\text{VCC}}$  – The symbol for the positive supply  $\underline{\text{voltage}}$  in a circuit. Also noted as  $V_{cc}$ .

<u>Volt</u> – The unit of potential difference or electromotive force, abbreviated V. One <u>volt</u> represents the potential difference needed to produce one <u>ampere</u> of current through a resistance of one ohm.

Voltage – The term used to designate electrical potential that causes current to flow.

<u>Volt-Ampere</u> – The unit of apparent power in an AC circuit containing capacitive or inductive reactance. The apparent power is the product of source <u>voltage</u> and current. Abbreviated VA.

<u>watt</u> – The unit of electrical power required to do work at the rate of one joule per second. One <u>watt</u> of power is expended when one <u>ampere</u> of direct current flows through a <u>resistance</u> of

one ohm. Abbreviated W.

Wet Contact – 1. Mercury-wetted contacts in sealed reed relays. When the contacts meet, the surface tension of the mercury draws the contacts together and forms a low-resistance path for low-level signals. In effect, the small amount of mercury ensures low-resistance contacts for low-level signals that don't clean the contacts. 2. Contacts through which current flows. *See:* Dry Contact.

**Zero-Crossing Detector** – A circuit that detects when an AC <u>voltage</u> signal has reached zero volts. Switching a circuit at this time reduces inrush currents and minimizes any EMI or RFI produced during switching.

#### For more information

We hope you found the **Appendix & amp; Glossary** useful. To go back to the Main Page, click here.

You can purchase the complete *Digital I/O Handbook* for only \$19.95 by clicking here. *The Digital I/O Handbook* is FREE with any qualifying Sealevel Digital I/O product purchase. You can find a listing of all Sealevel Digital I/O products by clicking here.

COMPUTING | SERIAL | I/O | ACCESSORIES | SUPPORT | CUSTOM SOLUTIONS | COMMUNITY | NEWS & EVENTS | COMPANY

CONTACT: 864.843.4343 tel | 864.843.3067 fax | support@sealevel.com | sales@sealevel.com | Sales & Privacy Policies

21 중 20 2018-06-07 오전 10:16

Proudly Made in the USA © Copyright 1996 - 2017, Sealevel Systems, Inc. All rights reserved











21 중 21 2018-06-07 오전 10:16